


User Manual

Functional schematic diagram of remote controller:



Matters needing attention:

1. The dial switch of the remote control must be consistent with the dial switch of the receiver in order to receive the signal.
2. The remote control uses a 12V23A battery. If the power is less than 50%, the remote control may be close or useless.
3. Do not install negative and positive electrodes when replacing batteries.
4. Technical parameter: Working voltage: 12V

Emission frequency: 303MHZ

Emission power: 6DB

Standby power: 5uA

Distance: 8-15M

Appearance size: 120*60*19MM

Warning

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the

equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter