

Front

7 cm

8.5 cm

TWS earphones
V5.0+EDR

Manual



FCC ID:2ATXKEB745071

Summary

- 1 Dust-proof mesh
- 2 Multifunction button
- 3 MIC
- 4 Charging port
- 5 Charging box light
- 6 Android charging port



1

Specifications:

TWS, real no wires design, individual left and right Channel, hifi sound, both the left and right earbuds are Bluetooth enabled. Could be used separately, or as one pair.

Bluetooth version:	V5.0+EDR (both sides), low consumption
Bluetooth Mode:	A2DP1.3/HFP1.6/HSP1.2/AVRCP1.6/D11.3
Bluetooth Frequency:	2.4GHZ
Bluetooth Range:	10 meters with no obstacles
Battery capacity:	Earbud: 45 mah rechargeable Li-ion battery Charging dock: 350mah (optional)
Talk/Play time:	Single earbud mode: 1-2 hours One pair earbuds mode: 1-2 hours
Standby time:	Single earbud mode: 100 hours One pair earbuds mode: 60 hours

About Pairing:

1. Pairing with one earbud: long press the multifunction button until the LED flashes in red and blue alternately, then turn on the Bluetooth on your device and select "i7-TWS" on your list. There would be a reminder voice saying "connected," then you could enjoy music or making phone calls. It supports reporting incoming calls.

2. Pairing with both sides:

- a. Long press the multifunction buttons of both sides at the same time until the LED is flashing in red and blue alternately;
- b. Then double click EITHER side to enter pairing mode. There would be a reminder voice "ready to pair."
- c. Turn on the Bluetooth on your device and choose "i7-TWS" to connect. When the LED flashes slowly in blue, they are paired successfully. Battery status displays on your cell phone.

2

NOTE: There would be two earbuds working when making / answering phone calls, but both sides could control power off/play/pause function individually when connected; the other one would be synchronized. Memory function supports connecting devices automatically.

Bluetooth usage:

1. Making phone calls:
Be sure the earphone is connected with your mobile phone, and then you can make phone calls. When making calls, there is two earphone working, and when there's an incoming call, it would broadcast calling numbers. You answer the call by slightly pressing the power button one time and refusing to answer by quick pressing the power button 2 times. When the earphones are in music mode, you dial your latest number by quick pressing the power button 2 times (redial the latest number).

2. Listening to music:

Be sure the earphone is connected with your mobile phone, then you can listen to music on your music list. Quickly press the power button to stop the music and replay by pressing again.

3. Power off:

Long press the power button until LED is red when not use; the Bluetooth device enters off mode. It would power off automatically when the earphone is away from your Bluetooth device for more than 5 minutes. No need to worry if power is exhausted.

4. Charging:

There is a reminder sound when battery is low, and the LED will flash red at the same time. When taking a charge, the LED will be red, and turns blue when fully charged.
Note: The earphone would be forced to shut down when charging, even if the power is ON before charging.

5. English language mode

3

Back

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

4



Warnings:

1. Please do not overuse this earphone or put it under heavy pressure. Keep away from water and heat.
2. Keep away from WiFi, router or other high-frequency transmitting equipment to prevent interruption of receiving a signal.
3. Please use this earphone under its working range (10 meters), and the effect would be better if there is no obstacle between the connected devices.
4. Use this Bluetooth earphone to connect any device with Bluetooth function.

5

DISTRIBUTED BY
Iscream
231 Croton Avenue
Cortlandt Manor, NY 10567

COMPANY
Shenzhen Jinwuxing
Electronics Co., Ltd.

FACTORY ADD
Building C, Si lian 228
Industry District, Henggang Town
Longgang Dist, Shenzhen China

MADE IN CHINA