

Before use

Insert the SD card into the device.

*Camera doesn't come with SD card, please buy on your own;
*Do not hot swap SD card.


Download APP

Scan the below QR code with mobile phone to download "B81". Android users can also find it on Google play, IOS users to find it on App store.



Configure network


In order to be able to monitor remotely, devices need to be connected to the Internet.



Start and configure the device

Please factory reset the device for the first time you use.

After the device is energized, it takes 15 seconds to startup the device successfully, press and hold the Reset button for 7 seconds. When you hear "restore factory settings" the voice prompt, reset completed.



Preview

The device is connected to the Internet, and users can configure and monitor devices on the APP.



tap “settings” to enter settings on device list, settings such as “network”, “video recording”, “alarm settings” and so on can be revised on this module.



FCC WARNING STATEMENT

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try correct the interference by one or more of the following measures:

- Reorient the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into and outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

FCC

1

2

- 3
- 4
- 5
- 6

7