




# NERO ONE GATEWAY

Smart System Controller



- 1 Connect your Gateway to your network using an Ethernet cable
- 2 Connect the power supply to your Gateway and allow it to fully boot
- 3 Go to [setup.environexus.com](http://setup.environexus.com) and follow the instructions to connect to your Gateway



- 1 Route cables through a 60mm hole and screw the mount to the wall
- 2 Click the Gateway down onto the wall mount, ensuring the Gateway is firmly locked on to the clips

*For further instructions & tips visit  
[support.environexus.com](http://support.environexus.com)*

## FCC Notice

THE MANUFACTURER IS NOT RESPONSIBLE FOR ANY RADIO OR TV INTERFERENCE CAUSED BY UNAUTHORIZED MODIFICATIONS TO THIS EQUIPMENT. SUCH MODIFICATIONS COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

## Important Disclaimer

Z-Wave Network wireless communication is inherently not always 100% reliable, and as such, this product should not be used in situations in which life and/or valuables are solely dependent on its function.

## Warning!

Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.

Contact your local government for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.



Blue Sky Technology Group Pty. Ltd.  
t/a Environexus

50 Ricketts Road  
Mount Waverley VIC 3149  
Australia

**Email:** support@environexus.com  
**Web:** www.environexus.com