


材质:105克 铜版纸 双面印刷 折页
尺寸:90x90mm

90.00 mm



Car type: Urban
 Battery Capacity: 3.7V 1200mAh/4.4Ah
 Rated Input: 5V0.5A (Max.)
 Rated Output: 5V0.5A (Max.)
 Bluetooth Version: 5.2
 Support: Handsfree, FM, Micro SD Card, USB
 Speaker: 408W 4x2mm
 Transmission distance: 30M
 Frequency response: 30Hz-20KHz
 Dimension: 120x110x60mm
 Weight: 515g

Tipo de célula: tipo 180
 Capacidad de la batería: 3, 7V 1200mAh/4.4Ah
 Tensión de Entrada: 5V/0.5A (máx.)
 Tensión de Salida: 5V/0.5A (máx.)
 Versión de Bluetooth: 5.2
 Compatibilidad: Android 3.0+, iOS 7.0+
 Almacenamiento: 4GB ROM/32GB
 Distancia de transmisión: 10M
 Requisitos de funcionamiento: 30-32°C
 Dimensiones: 70/41/100mm/100mm
 Peso: 515g/100g

Model: BT9081
Zieltemp.: 130 °C
Mischpatzteil: 3: 7V, 1200 mV/4,44 Wh
Eingangsspannung: 5V0.5A (Max.)
Ausgangsspannung: 5V0.5A (Max.)
Bluetooth-Vertrag.: 5.2
Unterstützung: Freisprechen, FM, Micro-SD-Karte
Ladepuffer: 40-8W/0.22mm
Unterstützungsspannung: 10V
Frequenzbereich: 1014-2104KHz


Gewichte : 5,55 ± 1,0g

Type de cartier : Universel
Capacité de la bobine : 3,7' 1200mm/44W
Encre : 5V0,5A (max)
Sortie : 5V/0,5A (max)
Version Bluetooth : 5.2
Mise en charge : 4,5h (avec 100%
Haut-parleur : 40 dB 920mm
Distance de transmission : 30M
Réponse en fréquence : 30Hz-20KHz
Dimensions : 120x110x100mm
Poids : 55x10g

100 di dati; 10 di 3V
 Capacità batteria: 1.7V
 (regolazione: 5V0, 5A Max)
 Potenza Normale: 5V0 5A (Max)
 Waveshare Bluetooth: 5.2
 Supporto: Marvell, F4, Sphero, MicroSD, U
 Alimentazione: 400W 400mm
 Distanza di trasmissione: 100m
 Risposta in frequenza: 30K-100KHz
 Dimensione: 120L x 100W x 100H (mm)
 Peso: 5.15kg 100

모델명 : BT3081
 배터리 : Lithum Ion
 해상도 : 3.7V 1500mAh/4.44Wh
 크기 (길이) : 50x50 (Max)
 크기 (폭) : 50x50 (Max)
 무게 : 52g
 충전 : 충전기 PA, 충전기 SD, USB
 전원 : 4.2-8.4V 0.5Amax
 입력 : 5V 100mA
 출력 : 5V 100mA

601.259 : 347
4271 : 515x109



1. Volume up/ Next Button
2. Volume Down/ Previous Button
3. Power/ LED Switch Button
4. Play/ Pause/ Mode Button
5. Recharge Port (Type-C DC 5V)
6. USB Flash Drive
7. Micro SD Card Slot

How to USE ?

1. Power (on): Turn on the power button (bottom of the speaker).
2. Bluetooth: Tap on the speaker to enter Bluetooth pairing mode, an indicator light will flash blue.
3. Bluetooth connection: Press Play/Pause, forward and backward (RTN/FF) buttons to connect to the device you want to pair.
4. Play and Pause: Press Play/Pause button on the device you paired the music.
5. Mode button: Long press the mode button to switch to bluetooth, FM, music SD card mode or USB play.
6. Volume: Press the volume up/down buttons to increase or decrease the volume.
7. Long press: Long press the play button to resume or pause the music.
8. Play next/Previous song press: Tap " " button the play next song/Previous " " button in any song press.
9. Micro SD card card: Insert music SD card or use the mode button, the speaker will automatically switch to SD card mode or use the mode button. The speaker supports MP3, AAC, WMA, FLAC, APE, WMA, and the file format.
10. USB play mode: Insert USB drive into the USB port. The speaker will automatically switch to USB play mode (USB to audio port).
11. USB A output: Change the output through USB A audio port.

Package Content



FCC Statement

[illegible]

Safety Instruction

- [illegible]

WARRANTY

All products from the date of purchase are qualified for limited time warranty. For more warranty information please visit <http://www.organo-powerbanks.com>

GARANTEE

Alle Produkte eignen sich ab dem Kaufdatum zu einer beschränkten Qualitätsgarantie an. Für weitere Informationen und den Anspruch auf eine kostenlose Reparatur oder einen Ersatz kontaktieren Sie bitte auf: <http://www.emulapowertools.com>

GARANTEE

Tous les articles bénéficient d'une garantie limitée dans le temps à partir de la date d'achat.

GARANZIA

GARANTIA
Todas las producciones desde la fecha de compra a gozan de la garantía de tiempo limitado. Para más información sobre la garantía, puedes visitar:
<http://www.energiaipowertools.com>



Power-Safe Management
Guarantees against short circuit and over-charging for your power bank and devices.



CUSTOMER SERVICE
For any question about the product, please contact us at service@energizerpowerbanks.com



FCC ID: 2AU4P-BT508

©2004 Emagister. Emagister Character and design graphic designs are trademarks of Emagister Brands, LLC and related subsidiaries and are used under license by Emagister International Corp.

UN_2_0750