

User manual

1. Open the app, allow authorized software location information, turn on Bluetooth, and start searching.
2. Open the iBeacon device, the standard ibeacon firmware, press and turn on the key to power on or off. After booting, it is directly connected to the mode, and automatically becomes unconnectable after 2 minutes.
3. In the APP search series, look for the name: iBeacon_n /PBeacon_n. If the suffix has _n, it means that it can be modified (when the Beacon device is close to the mobile phone, it is generally ranked in the top two). Click on the name to enter, indicating that the interface for modifying the parameters has been entered. The hardware will automatically obtain the UUID and related parameters. Click the link to enter the detailed parameter page.
4. Fill in the corresponding UUID, Major, Minor parameters, fill in the password 123456, enable.
5. After modifying the parameters, the iBeacon device will automatically shut down and the APP will return to the previous page.
6. Restart and the green light is on, that is, the modification is successful.

FCC Statement:

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement

This device complies with FCC RF radiation exposure limits set forth for an uncontrolled environment.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.