

product instruction

How to Properly Use Your PWRD Pro Bundle

1. Unbox Your PWRD Pro Bundle

After unboxing, locate your desired dongle attachment for your clippers.

2. Prepare the Dongle Attachment

- Ensure the magnet is facing up and the double-sided tape is facing down.
- Do not remove the tape backing just yet.

3. Clean the Clipper Surface

Before applying the tape, ensure the area of your clipper where the dongle will attach is clean and free of debris for a secure fit.

4. Apply the Dongle Attachment

- Remove the tab from the double-sided tape.
- Carefully press the dongle attachment onto the bottom of the clipper.
- Hold the attachment firmly in place for 30 seconds to ensure a strong bond.

5. Start Charging

Place your clipper on the charging mat. The magnetic dongle will automatically align and attach to the pogo pin for effortless charging.

6. Product Name: Hair Clipper Wireless Charger

Model: HCS-1

FCC ID: 2AU7D-HCS-1

Input: 12V 4A 48W

Output 1: Phone Wireless Charging 15W

Output 2/3/4/5: Hair Clipper Wireless Charging 5W

FCC Statement

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body.