

Item: UB-CH-QI918
UBIF: 130674

Description: UBIF Wireless Qi Charging Pad (USB-C), Black - 5W/7.5W/10W
Casing Color: Black
Date: 15th August 2019

Thank you for purchasing a premium quality **uBreakiFix** product. The Qi Certified Fast Wireless Charging Pad with 10W, 7.5W & 5W output levels is compatible with new iPhones, Samsung, Sony, LG and other Qi enabled smartphones, tablets or accessories. The perfect charging companion for any Qi enabled device, simply place and charge. Includes USB to USB-C cable.

Frequently Asked Questions

How do I use the wireless charger to charge my device?
Simply ensure the wireless charger is correctly connected to the USB-C cable and the other end is inserted correctly to a USB power adaptor. Place your Qi wireless charging enabled device onto the pad and a RED light will appear on the charging pad to indicate charging has commenced.

How do I know when my device is charged?
There are variations between different smartphone and tablet models, please check your device's user manual to confirm. In most cases the charge level will be shown as a battery symbol or percentage at the top of your device screen.

What power adaptor should I use with the wireless charger?
We recommend using a Qualcomm 3.0 certified USB power adaptor to ensure you will receive the maximum charging power available for your Qi enabled device. 7.5W and 10W Fast Charging Modes require the USB cable to be connected to a Qualcomm Quick Charge 2.0, 3.0 or above compliant power adaptor (not included). 5W Standard Charging Mode requires the USB cable to be connected to a 5V 2A USB power adaptor (not included). Fast Charging Modes require a Qi enabled Fast Charge device.

SUPPORT INFORMATION

Who do I contact for support?
Please contact your place of purchase or email us at support@ubreakifix.com

PACKAGE CONTENTS
1x Qi Wireless Fast Charging Pad
1x USB to USB-C Flat Cable, 3ft/1m
1x User Guide

WIRELESS CHARGER TECH. SPECIFICATIONS
SKU: 130674
Input: DC5V/2A, DC9V/1.67A
Output: 5W/7.5W/10W
Charging Distance: ≤10mm

CABLE TECH. SPECIFICATIONS
SKU: 130674
Connectors: USB-A to USB-C
Cable structure: Flat design with TPE material
Function: Supports sync and charge
Length: 3ft / 1m
Power: 3A Max


FC **RECYCLE**

qi **qi CERTIFIED FAST CHARGER**

©2019 uBreakiFix, E&OE. All Rights Reserved. All registered trademarks, trademarks, brand names or product names are the property of their respective owners. uBreakiFix is a registered trademark in the U.S. and other countries. USB-C is a trademark of USB Implementers Forum. Qualcomm Quick Charge is a product of Qualcomm Technologies, Inc. Qualcomm is a trademark of Qualcomm Incorporated, registered in the United States and other countries. Quick Charge is a trademark of Qualcomm Incorporated. All Qualcomm incorporated trademarks are used with permission. The Qi symbol is a trademark of the Wireless Power Consortium.


Made in China.

UBREAKIFIX. WIRELESS CHARGER
qi CERTIFIED / USB-C CABLE



User Guide


1. CONNECT USB END TO QC 2.0 / 3.0 OR USB POWER ADAPTOR
Insert the USB end of the cable into a USB power adaptor.




2. CONNECT USB-C TO WIRELESS CHARGER
Insert the USB-C end of the cable into the charging port of the Qi Wireless charger.

*NOTE: 7.5W and 10W Fast Charging Modes require the USB cable to be connected to a Qualcomm Quick Charge 2.0, 3.0 or above compliant power adaptor (not included). 5W Standard Charging Mode requires the USB cable to be connected to a 5V 2A USB power adaptor (not included). Fast Charging Modes require a Qi enabled Fast Charge device.

3. PLACE YOUR qi ENABLED DEVICE ONTO PAD TO CHARGE
Place your device centrally on the pad to charge. The charge icon will appear at the top of your device's screen.



4. LED CHARGE LIGHT
When the wireless charger is in standby mode a GREEN light will appear on the front of the pad and when your device begins charging a RED light will appear on the front of the pad to indicate charging has commenced. Once charging is completed, the light will change to GREEN. Note that the final light change to GREEN is supported by most smartphone models, but not all smartphone models available in the market support this feature.



IMPORTANT - SAFETY INFORMATION

Before use, please read the following important safety information. Following these guidelines and precautions will help to ensure trouble-free operation and optimal performance of the wireless charger and compatible electronic devices.

- Please use caution and care when handling any device with electrical power and inspect regularly to ensure the product is in good working order.
- Do not place items with magnetic strips or RFID chips onto the wireless charger pad, such as credit cards, security badges or passports as they may be damaged by the magnetic induction of the charger.
- Always leave space around the wireless charger and do not use the wireless charger in a location where airflow around the wireless charger is confined.
- Never force a connector into a port. If the connector and port do not join with reasonable ease, they may not match each other.
- Make sure that the connector matches the port and that you have positioned the connector correctly in relation to the port before plugging them together.
- It is normal for wireless chargers to become warm during use. Avoid touching the device during use. Avoid placing in direct sunlight or near heat sensitive materials.
- Before connecting anything to the wireless charger, make sure there are no foreign objects inside the device port or connector.
- Do not place any metal objects on the wireless charger pad.
- Never short circuit the USB port or other pins.

IMPORTANT - SAFETY INFORMATION (continued)

Before use, please read the following important safety information. Following these guidelines and precautions will help to ensure trouble-free operation and optimal performance of the wireless charger and compatible electronic devices.

- If you notice the wireless charger appears to be in any way damaged, cracked or broken please do not use the wireless charger and refer to your place of purchase.
- Never subject the wireless charger to mechanical shock, including, but not limited to dropping, crushing, bending or puncturing.
- For indoor use only. Avoid exposure to external heat sources; fire; direct prolonged sunlight; dust; corrosive chemicals or anything that may cause damage to the wireless charger.
- The wireless charger is not user-serviceable. Do not attempt to service or disassemble the charger in any way as it can result in electrical hazard, including harm. If you experience any problem with the unit, discontinue use immediately and contact your place of purchase for assistance. Attempting to open or service the unit voids all warranties, express or implied.
- Please refer to your country's governing electrical body for the latest information on handling products with electrical power.
- To reduce the chance of shock or injury, do not use your wireless charger in or near water or wet locations.
- When connecting or disconnecting your wireless charger, keep fingers away from the metal parts of any plugs.

FCC Warning Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.