








LED Floor Light User Manual

Features


-  16 million colors, RGB+IC digital color lighting.
-  Multiple control ways available, can be controlled by controller's switch button, IR remote and APP.
-  Support music sync function and various music modes available.
-  Voice controllable by third-party intelligent speaker like Alexa and Google Assistant etc.
-  Three wide-angle illuminated surfaces, no video flashing
-  Dual infrared heads for sensitive remote control operation

Product Parameters

Dimension	22*1350mm
Material	Aluminum+ABS+Silicone
Working voltage	DC 5V / DC 12V
Rated power	MAX.10W / MAX.18W
Communication protocol	Wifi(IEEE 802.11a/b/g/n)+BLE
Product function	Digital color,Music sync
Switch button function	ON/OFF switch,Modes adjustment,
APP control	Smart Life(Support various functions like brightness adjustment, music sync, mode switch and set timer etc.) 
IR remote control	Control distance: 0-5 meters
Voice control	Support third-party intelligent speaker like Alexa and Google Assistant etc.
Installation ways	four-segment connection
Working environment	-10~40°C


Operation

- Short press: Turn on the light,or modes adjustment
- Double-click: Shutdown
- Long press: Into quick flash internet pairing mode



APP Operation

- Download and install the APP of Smart Life, open your mobile phone's WiFi and BLE, long press the switch button for over 3 seconds to make the light into quick flash internet pairing mode. Search or add the device on the APP, and log in with the WiFi password to start internet pairing.
- After pairing success, you can start to operate the APP to control the light to change colors, adjust brightness, change the modes, set timer and share your accounts etc.



Voice control

Turn on the third-party intelligent speaker you want to connect like Alexa, Google Assistant etc. Make sure they connect to same WiFi, and go to the APP to search for the devices and get authorized, then you can voice control the lights with the standard command words.

Installation

- After unpacking, please pull out the connector and the silicone tube from the control box.
- Plug-in the metal light pole and use the screwdriver and screws to fix the light poles, 4pcs of light poles in total. Note: please press the light pole together with appropriate hand pressure while fixing the light poles.
- Please align the silicone tube with the end cap of the light poles, and insert and press the silicone tube into the light poles from top to bottom after all light poles connected.
- Before the silicone tube is pressed into the last piece of the light pole, plug-in the connector of the silicone tube into the control box.
- Check whether there is a gap between the upper part of the silicone tube and the end cap and if the silicone tube is pressed in place. After the silicone tube is assembled in place, clamp the plastic parts into the control box shell.
- After the light poles and silicone tube assembly finished, tighten the nut of the control box into the base clockwise to complete the installation.










Before plugging in the product, please confirm the voltage of the product or consult your customer service.

Remote controller operation

- Power supply: 3V button cell
- Control distance: 5-8 meters in open area

Remove the PVC film on the back of the remote controller before use, and press the power button before operation.



Features	Action	Remote control buttons
ON/OFF	Short Press	
Plasma/heat	Short Press	
Speed/sensitivity	Short Press	
Dynamic mode switching	Short Press	
Music mode	Short Press	
Automatic mode	Short Press	
Brightness +/-	Short Press	
Static color switching	Short Press	
W R G B	Short Press	

FCC Statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference.
 - (2) This device must accept any interference received, including interference that may cause undesired operation.
- Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment should be installed and operated with a minimum distance of 20 cm between the radiator and your body