



Wireless Charging Cradle

User Manual


Product	Wireless Charging Cradle
Model Name	MC-D114
Variant Model Name	None
Manufacturer	CELLRETURN CO.,LTD
Ver.	V0.1

1. Read me first

Please read this manual before using the device to ensure safe and proper use.

- Images may differ in appearance from the actual product. Content is subject to change without prior notice.
- Before using the wireless charger, make sure it is compatible with your device.

2. Device layout



서식 있음: 글꼴: (영어) Times New Roman, 11 pt


3. Using the wireless charger

Charging your LED MASK PLATINUM

Connect the charger to the wireless charger.

When the LED MASK PLATINUM is correctly placed on the wireless charger, the indicator light turns on blue.

Check the charging LED indicator on the MASK for charging status.



When the LED MASK is fully charged, removed the MASK from the wireless charger.

Indicator light identification

The indicator light alerts you to the wireless charger's status.

Colour	Status
Off	When connected to a power outlet
Blue	When the LED MASK PLATINUM is correctly placed on the wireless charger
Off	When the MASK is removed from the wireless charger or when the wireless charger is not connected to a power outlet



Wireless Charging Cradle

4. Precautions for LED MASK PLATINUM charging

- Do not place the MASK on the wireless charger with a credit card or radiofrequency identification (RFID) card (such as a transportation card or a key card).
- Do not place the MASK on the wireless charger when conductive materials, such as metal objects and magnets, are placed between the MASK and the wireless charger
- Do not connect a charger to the MASK during wireless charging at the same time, When the MASK is charged both way wired and wireless at the same time, it might be able to make problem.
- When charging for LED MASK PLATINUM, should keep a distance more than 15 cm between wireless charging cradle and human body.
- To save energy, unplug the charger when not in use. The charger does not have a power switch,
so you must unplug the charger from the electric socket when not in use to avoid wasting power.

The charger should remain close to the electric socket and easily accessible while charging.

5. Specifications

Model Name	MC-D114
Input power	d.c. 5 V/2 A
Wireless charging	Qi (Tx)
Weight	662 g
Size	26.8 x 18.2 x 24.0 cm (W x H x D)



Wireless Charging Cradle

FCC Compliance Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.