

KD-100



P-1 FEATURES

Thank you for choosing and buying this digital piano to congratulate you on becoming the music p layer of the digital piano. This digital piano elegant and exquisite is the perfect combination of the feel and sound quality of the traditional piano and the latest electronic technology of the conte mporary era, so that you can enjoy great music fun.
Please read this manual in detail before using this instrument.
Please be sure to keep all user documents in good custody so that they can be consulted when need ed in the future.

Using DREAM Dream Sound Source
Its core uses French DREAM dream sound source, digital sampling, for your performance to bring the realistic auditory experience.

88 progressive counterweight keys
The 88 key gradual counterweight keyboard gives you the real touch of playing on the grand piano.

progressive hammer action keyboard


Headphone Jack

External double earphone Jack, easy to play without affecting others

Bottom left of the piano body



1



P-2 INSTALLATION


- 1-1 to 1-4 Plastic handle screw M6*25(4 grains)
- 2-1 to 2-4 Cross recessed raised countersunk head tapping screws M6*60 (4 grains)
- 3-1 to 3-4 Cross recessed raised countersunk head furniture screws M6*50 (4 grains)
- 4-1 Screw with plastic handle M6*35 (1 grain)

Attention: the screw of footplate support should contact with the ground closely after installation

P-3 OPERATIONS

Mp3 Bluetooth Receiving Module Function Description

1. USB flash drive is in running status after turning on the "POWER" switch.
2. Long press on (ON/OFF) key then enter into Bluetooth status (Bluetooth light flashes quickly). The light flashes slowly after connected
3. Press on ON/OFF to realize Play/Pause
4. Quick click on "Next" to switch the next song.
Long press on "Vol+" to increase the volume
5. Quick click on "Prev" to switch the previous song.
Long press on "Vol-" to reduce the volume
6. It can be operated by remote control
7. Name of Bluetooth: Xiong Hai Piano



2

P-4

Operations

1 Power Cord connection.
when used, connect to the power cord as illustrated, one end plugged into the power jack in the bot tom of the piano operating board and 220V household power outlet at the other end. (figure 1).
***When you do not use this product for a long time, please unplug the power cord and properly sec ure your business.**

2. Piano play

1. Press the Power switch to the on position and the Power LED is lit to enter the playing state. (fi gure 3) (figure 4)
 2. Play music on the piano keyboard.
 3. Turn off the power supply when not in use for the time being.
- *This product processor chip is complex, similar to the computer system, sometimes can not respo nd, please turn off the power switch and then turn on the normal work.**

Note! A product is specially designed and manufactured for piano learners and performers, so onl y the correct piano tone!

3 Volume control

with the "volume" knobs to increase or reduce the volume of the piano, the volume to the satisfacti on of the position. (figure 5)

4 Pedal using

this product has three pedals corresponding to "weak tone / late tone / sustain tone" three functions, when using, step on the appropriate pedal as needed.

weak tone / late tone / sustain tone"

1. Headphone

This product has two headphone sockets. Connecting the headset will automatically cut off th e output of the internal field microphone of the electronic piano, so that no one else will be dis turbed when the sound is cool. Two sets of headphones can be plugged in at the same time, an d when used, the headphones can be accessed as illustrated (figure 6)

P-5

PRODUCT CARE

To do a good job of the product's order and protection work, to prolong the service life of the prod uct, reduce the fault has a very important role.

1. Avoid heat, moisture, or direct sunlight. Do not over-expose the product to direct sunlight, or pl ace it close to the air-conditioning or extreme heat.
2. Do not use this product near the television or radio which may cause video or audio interference to the reception of the television and radio. If this happens, the product should be removed from t he television or radio.
3. Paint, diluents or similar chemicals shall not be used to clean the product with a soft cloth wet with a weak aqueous solution and a neutral wash. Soak the cloth in the solution and screw it dry u ntil it is close to drying.
4. Do not shake, avoid collision products in the movement should be carefully placed, severe vibration and collision is strictly prohibited, so as not to cause damage to the casing or internal electronic components.

3

APPENDIX

Appendix attachment list

name	quantity
power cord	1PCS
Body of piano	1PCS
pedal crossbar	1PCS
left / right support plate	2PCS
front / right support column	2PCS
front and back retainer	2PCS
bolt	4PCS
screw	31PCS
certificate	1 PCS
specification	1 PCS
iron	6 PCS

Musical instrument parameter harp

key: 88 key
range: A2-C5
style: vertical piano
tone: < 3
sub-output power: ≥ 40W·2
power parameter: AC 220V 50Hz

4

P-7

Precautions

Power supply

This product can be powered by standard indoor wall sockets, please use only the power cord spec -ified in this product. When not in use, be sure to turn off the power supply. If you do not use it for a long time, unplug the power cord and keep it in good care.

Sign

This specification and product are marked with a series of safety marks to ensure that you use this product safely and correctly, to prevent harm to users and others, and to cause financial damage. The signs and their meanings are as follows:



Warning

Sign indicates that ignoring this logo and misoperating the product poses a potential risk of death or serious injury.



Attention

A Note this flag indicates that there is a potential risk of personal injury or other financial damage if the wrong operation of this product is ignored.



Eg: This triangle flag indicates what the user should be aware of. (the left example is to be careful wit h electrocution)



The circular sign with a slash indicates the prohibition. The icon in or next to the flag indicates wha t is specifically prohibited.



The black dot indicates what must be observed. The icon in this flag indicates the contents of the s pecific compliance. (the left example is that the power plug must be unplugged from the socket)

5

P-8

PRECAUTIONS

Warning

smoky, smelly, overheated

when this product smokes, smells, or overheats, continuing to use risks of fire and electric sh ock when the product is smoking, smelling, or overheating. The following should be done immedi ately in the event of such a situation.

1. switch it off.
2. Unplug the plug from the power outlet.
3. Contacting your reseller with an improper

Power cord

Use of the power cord is a risk of fire and electrocution. The following considerations must be obs erved.

The dedicated power cord specified for this product must be used.
The output voltage must be used at home within the rated voltage range of AC power supply should not overload the power outlet and power supply extension line.

Improper handling of the power cord leads to damage or fracture causing fire and electrical shock risk. The following considerations must be observed.

- Do not place or heat heavy objects on the power cord.
- Do not attempt to modify or bend the power cord too much.
- Do not twist or pull the power cord.
- If the power cord or plug is damaged, replace the same type of power supply by using the po wer cord where water is not guttered.
- Do not place vases or any other containers containing water on this product. Water is in dang er of causing fire and electric shock.
- Do not allow minors to plug and touch the power cord or connection board, minors do not us e electricity safety knowledge, there is a danger of electric shock.

Note

the improper use of the power cord poses a risk of fire and electrocution. The following considerr ions must be observed.

- Do not place the power cord near the furnace or other heat sources.
- Do not pull the power cord when unplugged from the power outlet, the heart must hold on to the plug body.

The power cord plug must be plugged into the power outlet to the Zhuang.
Make sure the power supply is shut down before connecting or cutting off the power cord. W hen a thunderstorm occurs, or before traveling or other long-term departure, unplug the electr ical outlet on the wall.

At least once a year, remove the power cord from the power outlet on the wall and clean the d ust accumulated around the plug.

6

P-9

PRECAUTIONS



Do not discard this product

do not put this product in the fire. Otherwise, it will cause the burning of wood products and t he explosion of their internal electronic components, which may cause fire and injury to people.

Water and other things

the entry of water and foreign water, other liquids and (metal sheets, etc.) into this product po ses a risk of fire and electrocution. The following should be done immediately in the event of such a situation.

1. switch it off.
2. If you are using the power cord for power supply, unplug it from the wall outlet.
3. Contact your dealer.

Disassembly and Remodel

do not disassemble or transform this product in any way. Otherwise, there is a risk of electric u sion, scald, or other personal injury. All internal inspection, adjustment and maintenance operatio ns should be entrusted to your dealer.

Fall or Crash

To drop or impact this product after falling or being damaged by a strong impact. There is a risk of fire and electrocution caused by the continued use of the product. The following should be done immediately in the event of such a situation.

1. switch it off.
2. If you are using the power cord for power supply, unplug it from the wall outlet.
3. Contact your dealer.

Plastic bags

must not be intended for the packaging of this product on the head or put in the plastic bags, otherwise there is a risk of asphyxiation, families with young children should pay special attentio n.

Keep away from this product and bracket

climb onto the body or its bracket at risk of overturning or damage. Families with young children should pay special attention to it.

Location

the product should be placed on an uneven surface or any other unstable place in such a way as to avoid placing the product on an uneven surface or in any other unstable place. Otherwise, it will cause this product to fall, there is a risk of causing injury to the personnel.

Moving

before moving the product, all other cables and connections must be removed from the power outlet on the wall and all other cables and connections must be unplugged from the power outlet o n the wall. Otherwise, there is a danger of line damage, fire and electric shock.

Cleaning

before cleaning this product, you must unplug the power cord from the power outlet on the w all before cleaning the product, otherwise there is a danger of fire and electric shock.

Interface

the interface can only connect the specified device and device on the interface of this product. Connecting non-designated equipment or devices poses a risk of fire and electrocution.

7

P-10

PRECAUTIONS

Location selection

should avoid placing the product in the following locations. Otherwise, there is a danger of fire and electric shock.

A place where the temperature is high or where there is only a lot of dust.

A kitchen or other place with fumes.

A place that is exposed to direct sunlight, or any other place where the product will heat up.

Volume

Do not play music at high volume for long periods of time. Be careful when using headphones. Too high a volume will damage your hearing.

Heavy objects


Heavy objects must not be placed on this product. Otherwise, the top of this product will be overweight, causing the product to overturn or make it fall on the object, there is a risk of causing injury to personnel.

The correct assembly of the bracket

The incorrect assembly of the bracket will cause the agent to overturn and cause the product to fall, and there is a risk that the person will be injured. Therefore, assembly must be carried out in accordance with the instructions attached to it to ensure that the product is properly installed on its bracket.

Fuse replacement

If the fuse break, the product may have a short circuit phenomenon, or voltage instability phenomenon, need to be identified and replaced by professional personnel, otherwise there is a risk of fire and electric shock.



8

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception,
—Reorient or relocate the receiving antenna.

—Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

—Consult the dealer or an experienced radio/TV technician for help.

FCC RF Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction