


Read the manual before use

Important: Plug in the charging wire for charging at the first time after receiving the goods, and use it after fully charging, which can make the Wireless earphone last longer

Important: Do not use super fast charging with current above 2A to avoid damaging the circuit chip due to excessive current



Open the cover and take out the earphones. The two earphones flash alternately from red to blue, and turn into one earphone's red and blue light flashing, and one earphone's light off, that is, the pairing is successful



Turn on Wireless on your mobile phone, search for Digital Pro4 devices and click on the connection.



The phone is successfully connected. Both headphone lights are off

the earphone touch control is marked in red circle




If only one headset has sound, please delete the connected "Digital Pro 4" first, turn off the wireless function of the phone, the headset needs to be paired once, enter the tws mode, and then return to the first step

The connection steps are as follows:

Open the cover of the phone, first make sure the Wireless of the phone is off, Take out the two earphones from the charging case, wait for 10 seconds, the earphone indicator light changes from fast flash to one earphone red and blue light blinking, one earphone light off, it means the earphones have been paired. Open the Wireless of your cell phone, search for "Digital Pro 4", click to connect

Touch function

1. Touch the headset once to answer or hang up a call
2. Tap the headset twice - previous/change
3. Touch the headset three times to reduce/increase the volume
4. Long press the earphone touch area for 1.5s to start Siri



The power delivered by the charger must be between min 2.5 Watts required by the radio equipment, and max 10 Watts in order to achieve the maximum charging speed.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.