

Size: 150 x 220mm

VISTATECH

Multi-Functional **Portable Fan** With Wireless Speaker

Instruction Manual

To charge the wireless speaker:

1. Ensure the wireless speaker is turned off.
2. Connect the wireless speaker to your computer or DC 5V USB adaptor using the micro USB charging cable provided.
3. A red LED light will illuminate to indicate that the speaker is charging.
4. Once fully charged, unplug the speaker from the charging cable.

Wireless mode:

1. Long press the power button "▶" for 3 seconds to power on.
2. Upon powering on, the default mode is wireless.
3. Enable Bluetooth on your mobile phone and connect to "NV-08678" for a successful connection.
4. Press the play/pause button "▶||" to play and pause music.
5. Use the previous track button "||◀" to go to the previous track, and the next track button "▶||" to skip to the next track.
6. Hold the volume down button "||◀" to decrease volume, and press the volume up button "▶||" to increase volume.

TF mode:

Insert the TF card into the slot, and it will automatically search and play the stored music.

Press "▶||" to play and pause.

Press "||◀" to previous track and press "▶||" to next track.

Hold "||◀" to decrease volume and press "▶||" to increase volume.

Radio mode:

Long press "▶" (for 3 seconds) to power on.

After powering on, the default mode is wireless mode.

Press "M" to switch to radio mode.


Long press "▶||" to automatically search for radio stations. Once the stations are found, they will be automatically saved.

Press "||◀" or "▶||" key to switch between channels.

Hold "||◀" to decrease volume and press "▶||" to increase volume.

Notes:

In radio mode, please insert the USB charging cable into the charging port as an external antenna for better radio reception.



Fan:

Long press "▶" (for 3 seconds) to power on.
Press "▶" to change the fan speed.

1. Low
2. Normal
3. High
4. Off

Usage precautions:

- Use the product only for its intended purpose.
- If the product was shipped in subzero temperatures, allow it to acclimate in a warm place (+16-25°C) for 3 hours before operation.
- Turn off the device when not in use for an extended period.
- Avoid exposing the product to vibrations and mechanical stress that could cause damage.
- Note that mechanical damage voids warranties.
- Do not attempt to disassemble the product, as it contains parts that cannot be self-repaired.
- Keep the product away from children under the age of 3, as it may contain small parts.
- Operate the product within the recommended temperature range (refer to the operation manual) and avoid use in humid or harsh environments.
- Do not use the product if it shows visible damage or obvious defects.
- Do not use the product for industrial, medical, or manufacturing purposes.
- Upon receiving the product, inspect it for damage and ensure there are no loose objects inside.



FCC Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.