

| |
|--|
| Precautions for use Do not immerse the printer in water or expose it to rain, otherwise the printer may be damaged. Do not open the paper compartment cover during printing, as this may cause the printer to malfunction. When printing using Bluetooth, the distance during printing cannot exceed 10 meters, otherwise it may cause garbled printing or unprintable. Although the printer can operate stably from 0 ° C to 45 ° C, excessive ambient temperature (45 ° C) or too low ambient temperature (0 ° C) can result in reduced print quality. Using poor quality paper or paper that has been stored for too long may result in reduced print quality or even damage to the printer. The printer tries to use up and recharge the battery before charging, which can effectively guarantee the battery life. |
|--|

| |
|---|
| Caveat This product has a built-in lithium battery, do not use it in an environment where the temperature is higher than 45 °C, do not place it near open flames or other heat sources, do not place it in hot sunlight, otherwise it may cause an explosion or fire hazard. Do not disassemble and replace the battery, if you replace the battery, you must use the same size battery, otherwise there is a danger of explosion. Used batteries are recycled or disposed of when in accordance with local regulations and product instruction manuals. Note that the thermal head of the print head is a hot component. It is strictly forbidden to touch the thermal sensor part during printing or at the end of printing! Note that the paper exit tearing blade is sharp, please be careful not to touch! |
|---|

| |
|---|
| Printer cleaning The printer should be cleaned in a timely manner when the printer: 1. The printing is not clear; 2. The printed page is not clear in the vertical direction; The cleaning steps for the print head are as follows: 1. Turn off the printer power, open the top cover, and remove the paper if there is paper; 2. If you have just finished printing, you should wait for the print head to cool completely; 3. Use a soft cotton cloth and absolute ethanol (should be wrung out) to wipe off the dust and stain on the surface of the thermal head of the print head; 4. After waiting for the absolute evaporation of absolute ethanol, close the upper cover and re-test the machine to print; |
|---|

Statement

This product is a Class A product and may cause radio interference in a living environment. In this case, the customer may be required to take practical measures to interfere with it.

| |
|--|
| FCC Statement Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: |
|--|

| |
|---|
| -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction. |
|---|

| |
|--|
| Due to product updates, some details of this document may not match the product, please prevail in kind! The manufacturer has the right to modify the content of this document without prior notice! |
|--|

Service Information

Customer service line: 0756-2897617
Official website: www.starpany.cn


Manufacturer: Zhuhai yike intelligent technology co., Ltd.
Manufacturer Address: 307-2, Zhonglixing Building, No. 4 Xingguo Street, Xiangzhou District, Zhuhai



Star machine

Quick start guide


PackingList



Product introduction

Product Name: Star Machine
Charging input: 5V ==1A
Battery: Built-in7.4V/1000mAh lithium battery
Printing method: thermal printing
Product Size: 86x86x41.2mm
Print speed: MAX 9mm/s
Supplies specifications: 57x30mm
Working environment: Temperature: 0~45°C
Humidity: 10~80%
operating system: Android/IOS

Key Functions



Download APP



Installation steps

1. the first use, long press the star machine to open the key 2 seconds to boot, double-click to open the key after booting, the star opportunity automatically print out the QR code.
2. Search for "Star Machine" in the application store or scan the QR code in the figure below to download and install the Star Machine APP. During the installati on process, the application is allowed to obtain the relevant permissions of the mobile phone, register the account and log in.
3. Open the APP, scan the QR code printed in step 1, and connect to Bluetooth. If the connection is successful, you can use APP to print.

Product warranty card

Product name : _____
Product model : _____
Product numer : _____
Date of purchase : _____

Warranty period: From the date of purchase, our company provides one-year warranty service.
The following situations will not be provided free warranty:
-Unauthorized disassembly of repair products
-Product barcode, fragile sticker damage and warranty card alteration and defect.
-Failure to operate the equipment in accordance with the instructions.
-Damage caused by water ingress or falling.
-Due to force majeure caused by failure or damage.
-Outside the warranty period.

Contact number: 0756-2897617

Company Address: 307-2, Zhonglixing Building, No. 4 Xingguo Street, Xiangzhou District, Zhuhai

facebook



Xprinter WEB



twitter



YouTube



WeChat



LinkedIn

