



☎ - 888.493.5559

✉ - INFO@ESLVISION.COM

🌐 - WWW.ESLVISION.COM


📍 - 1136 SOUTH 3600 WEST SALT LAKE CITY, UTAH 84104

User manual

Model: ESL-SPETAP-WH-75W-V1

1. This product (module) is used in ESL Visions ESL-DVAN-SLR/PNL product series. The module can be connected to a DVAN driver to achieve 0-10 dimming. It can also work with an ESL VISION App to perform other functionalism.
2. To download ESL Vision's APP, you can visit www.eslvision.com or find it in the app store
3. Once the module is learned-in via the ESL Vision APP. The user will be able to set specified settings such as 0-10V Dimming, high and trim, LED driver ON / OFF, and real-time power monitoring, grouping and other such features.
4. Please make sure this product is set up with the corresponding DVAN driver model.
5. For how to use ESL Vision's app to control the TAP Module, please refer to the ESL Vision app manual.
6. Bluetooth Version: V4.1

APP introduction:



Country/Region 中国(+86) >

password

forgot password 2

1 create account


The Login page:

- 1: new account registration
- 2: account login, forgot password, you can retrieve password



3: For new account registration, you can choose Mobile number or Email address to register according to the country or region. Mobile number, Email address accept the verification code, and also serve as a login account.

4: When registering, set the account password at the same time.



5: PRESETS

6: DEVICES

7: GROUPS

8: SCENES

9: SCHEDULES

10: ALERTS

11: REPORTS

12: ACCOUNT

13: ABOUT



☎ - 888.493.5559

✉ - INFO@ESLVISION.COM

🌐 - WWW.ESLVISION.COM

📍 - 1136 SOUTH 3600 WEST SALT LAKE CITY, UTAH 84104

FCC STATEMENT

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void your authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement, the device can be used in portable exposure condition without restriction.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver
Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.