






PRODUCT USAGE EXAMPLE

Once connected Piano Hi-Lite to your smart device successfully, The ONE Piano Hi-Lite will light up to indicate which keys or notes are supposed to play according to song/game/video lesson that you want to play. In this way, blue lights represent left hand notes, and the red lights represent right hand notes. Follow the blue lights with your left hand, and follow the red lights with your right hand. Once you press the correct key, the light will move to the next key. You just need to follow the light's guiding.







SPECIFICATION

Dimensions	1233mm length , 22.5mm Width, 23.5mm Height
Power Source	5V/1A
Output power	5W
Net Weight	600g
LED Lights	88 red and blue highlight LED lights
Interface	Micro USB, Bluetooth4.0
Versions	2.0

NO.25191105



This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID: 2AUX9-TOH2





The **ONE**[®]

Piano Hi-Lite^(2.0)
User Manual

TOH2 FCC ID:2AUX9-T0H2

www.smartpiano.com



1

