


## User Instructions for Remote



|               |          |
|---------------|----------|
| Model No.     | RDNA042C |
| Rated Voltage | 3VDC     |

### ! WARNINGS AND CAUTIONS

1. Chemical Burn Hazard. Keep batteries away from children.
2. This product contains a lithium button/coin cell battery. If a new or used lithium button/coin cell battery is swallowed or enters the body, it can cause severe internal burns and can lead to death in as little as 2 hours. Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
3. The cells shall be disposed of properly, including keeping them away from children.
4. Even used cells may cause injury.

### RF EXPOSURE STATEMENT

This equipment complies with the FCC RF radiation exposure limits set forth for an uncontrolled environment.

This equipment meets the exemption from the routine evaluation limits in section 2.5 of RSS-102.

Cet équipement est conforme à l'exemption des limites d'évaluation habituelle de la section 2.5 de la norme RSS-102.

### IC Information

This device contains licence-exempt transmitter(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. L'appareil ne doit pas produire de brouillage;
2. L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

### FCC Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**11. Dimming Button (UP)**

2.11.1 Short press the dimming button once can increase a level of brightness when in ON status.

2.11.2 Long press the dimming button can continuous to increase the brightness until release or reach the max.brightness.

2.11.3 Short press the dimming button(up) 2 times continuously when in ON/OFF status to turn quickly to the max. brightness.

**12. Dimming Button (Down)**

2.12.1 Short press the dimming button once can decrease a level of brightness when in ON status.

2.12.2 Long press the dimming button can continuous to decrease the brightness until release or reach the min.brightness.


2.12.3 Continuous short press 2 times when in ON/OFF status to turn quickly to the min. brightness.

### FCC CAUTION


Any changes or modifications to this unit not expressly approved by the manufacturer could void the user's authority to operate the equipment.

### Remote Control

Note:  
1. The battery of the remote control can be replaced.  
2. Battery model: CR2032.



### Accessory Information




### 3. Tools Needed To Install

|                          |             |
|--------------------------|-------------|
| Φ5mm Philips Screwdriver | Test Pencil |
| Electrical Tape          | Plier       |
| Cutter                   | Ruler       |


### 4. Installation

**4.1.1** Installing the base to fixed the remote control (Installation the junction box with panel)

- Installation the Junction box auxiliary bracket on the Junction box bracket.




- Secure the junction box bracket securely with the mounting screws provided.




### 4.1.2 Installing the panel

- Installing the panel base on the Junction box bracket and tighten with the matched screws.



- Put the panel on the panel base, press gently to make it to make sure it installed firmly.



- according to the junction box bracket hole, drill two holes on the wall, and into the expansion bolt, with mounting screws to junction box support fixation.




### 4.2.1 Wall installing with panel

- according to the junction box bracket hole, drill two holes on the wall, and into the expansion bolt, with mounting screws to junction box support fixation.




### 4.2.2 Installing the panel

- Installing the panel base on the Junction box bracket and tighten with the matched screws.



- Put the panel on the panel base, press gently to make it to make sure it installed firmly.




- remove the old battery from the battery holder, change new battery (CR2032), Reinstall the battery box on the remote control.




### 4.3 Wall installing without panel

- Mode one : Peel off the wall bracket's stripping layer of back adhesive and attach the wall bracket to the wall and fix it firmly.




- Mode two: according to the wall bracket hole, drill two holes on the wall, and into the expansion bolt, the wall bracket with mounting screws fixation.




### 4.4 Remote control battery replacement

- Hold the card buckle both ends of the battery compartment pull it out, then remove the battery compartment.



- Put the panel on the panel base, press gently to make it to make sure it installed firmly.



- remove the old battery from the battery holder, change new battery (CR2032), Reinstall the battery box on the remote control.

