


# EPM001 User Manual

## 1. Outlook:



1. USB/TF slot	2. PIR slot	3. Reed slot	4. Touch slot	5. Touch slot
6. Reed slot	7. Reed slot	8. Reset	9. Main button	10. Battery bay

## 2. Button definition:

Main button: Short press once to take a photo, send the photo and battery information to the specified server

Long press for 5 seconds to configure the WiFi manually

Reset: Insert the TF card which contains upgrade file to the device, long press the button to turn on, then after 5 seconds, the red/blue button light will flash, then release the button, the device will upgrade automatically, the button light will distinguish when upgrade ends.

## 3. Slot definition

USB: Charge, Connecting PC for storing data

TF: Store photos and save upgrade file

Sensor: Reed 3pcs, Touch 2pcs, PIR 1pc

#### 4. Working status

Device operation and background interaction:

- a. Short press the main button: Short press the main button, the red button light flashes once and the buzzer beeps 3 times, and simultaneously sends the current photo to the server;
- b. Sensor detection signal (Reed, Touch, PIR; see note below): When the sensor detects a signal change, the red button flashes once and the buzzer beeps 6 times, send the current photo to the server at the same time;

Remarks:

Reed: Magnetic trigger switch, when the magnet leaves the sensor switch, a trigger is generated, and the white light is illuminated when the camera is triggered;

Touch: Touch switch, a trigger is generated when touched, and the infrared light is illuminated when the photograph is triggered;

PIR: IR sensor switch, triggered when a living body movement is detected, and the infrared light is illuminated when the photograph is triggered;

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

RF exposure warning :

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment shall be installed and operated with minimum distance 20cm between the radiator & body.