



60W Bluetooth 2.1 channel multimedia speaker

Matters needing attention

- Please refer to the product specifications before use to confirm whether the product is applicable.
- Please turn down the volume first to avoid the original set volume of the device is too large and causing damage.
- When odor and smoke are found, cut off the power supply immediately and remove the plug.
- To prevent the risk of fire or electric shock, do not expose this appliance to rain or moisture.

NCC Aphorism

The low-power RF equipment that has obtained the inspection certificate shall not be approved, and the company, manufacturer or user shall not arbitrarily change the frequency, increase the power or change the characteristics and functions of the original design. The use of low-power RF devices shall not affect flight safety or interfere with legitimate communications; When any phenomena are found, immediately stop using, and improve to no dry consumption can continue to use. The aforesaid lawful communication means that radio communication and low power radio frequency equipment operating in accordance with the provisions of the Telecommunications Administration Law shall be subjected to the review of legal communication or radio wave radiation electrical equipment for industrial, scientific and medical use

Key description

MODE (Mode Conversion) Tap to switch Bluetooth /USB/SD card/external source mode
 Previous song Short press to cut to the previous track, long press volume reduction
 Play/pause In any mode, tap to start or pause music
 Next song Short press to cut to the next song, long press volume plus

Bluetooth playback

After the setting is completed for the first time, the next use does not need to be set again, the product will automatically connect

Mobile phone Bluetooth setting method

- Please confirm that the Bluetooth of the mobile phone is enabled
- Turn on the switch button, press the MODE button, and the indicator blinks
- Enter the phone Bluetooth "MM1208", click Connect
 If the device is successfully paired, you will hear the connected prompt tone and start playing music
- **•** Indicates key play or pause **◀▶** Buttons change the music

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and

(2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.



USB/SD card playback

1. Toggle button
2. Insert a USB or SD card into the card slot to play music

External audio source play

1. Toggle button
2. Use the built-in audio source cable to connect to the external device, and connect the other end to the main speaker to start playing music
3. In source input mode, you cannot switch between previous and next tracks on the host speaker, but you can switch between connected devices Upper control