


Specifications:		
Bluetooth wireless 5.3		
True Wireless Stereo (TWS)		
Flickering LED flame effects		
Up to 24 hour battery life		
IPX4 water resistant design		
Party Plus: pair both speakers with ease		
On-speaker controls		
Built-in rechargeable batteries		
Speaker sensitivity: 85dB		
Includes:		
2 Bluetooth speakers		
2 removable ground stakes		
2 wall mounts		
2 hanging hooks		
2 Micro-USB cables		

Bluetooth speaker with LED FLAME



	Operation method	
	<p>Flame light speaker button instructions:</p> <p>1)Long press the play button to pair TWS. 2)Double press the play button to pair Bluetooth. 3)Press the power switch twice to activate the voice switch,and set the voice switch on/off. Long press and short press the VOL+/- keys are both sound volume for small and big.</p>	<p>Pause key:</p> <p>1) Press and hold for 3 seconds in Bluetooth free mode to report Bluetooth Connection</p> <p>2) Connecting the speaker to the phone via Bluetooth and long pressing for 3 seconds will disconnect the connection</p> <p>3) If the speaker has been paired with a mobile phone via Bluetooth, long press will reconnect</p>

## **FCC Warning**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.