

Welcome to the iopool family!

Dear Madam or Sir,

Thank you again for choosing iopool for your pool maintenance.

In your Eco START package, you will find:

- Your Eco pool assistant,
- 5 calibration strips and their reference card,
- A calibrated white spoon for all granular/powder products,
- Your first maintenance products to start your treatment.

About your Eco :

- It has a 2-year battery-life, no need to recharge it.
- It hates being out of the water. Once the rubber cap is turned over, be sure to leave the Eco in the water at all times.

Start guide

1. Download the iopool app on your smartphone



2. Create your account,
3. Create your pool in the App,
4. Link your Eco monitor (if you have one),
5. Scan your pack's QR code =>



iopool.com



This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.