


INSTRUCTIONS FOR USE OF HIGH-SPEED VEHICLES

Please read the instruction manual carefully before use, please keep the instruction manual for future use


PACKING LIST




BATTERY INSTALLATION AND CHARGING FOR STUNT CARS AND REMOTE CONTROLS




Connect the battery to the charging cable, then plug the USB charging cable into the computer's USB port or a 5V output USB charger, and then turn on the power. When the red light is on, it means charging. When the red light does not light up, it means full.



Remote control battery installation method
(1) Open the battery cover on the bottom of the remote control
(2) Insert 3 1.5V "AA" batteries according to the correct polarity, and close the battery cover.





After charging is complete, open the battery cover and place the battery in the battery compartment.




Connect the interface between the battery pack and the body, and close the battery cover.

REMOTE CONTROL FUNCTION





INSTRUCTIONS

1. Turn the power switch of the remote control car to the "ON" position. Put the remote control car on a level surface, then turn on the remote control switch, and when the remote control indicator light stops flashing, you can turn the joystick to operate. (Note: The joystick cannot be moved when the indicator light of the remote control is flashing)



IBASIC OPERATION DIAGRAM OF PRODUCT USE



2. Brake button: Press the brake button during high-speed driving to brake.
3. High and low speed button: The factory default low speed gear, press the switch button once, the remote control car will switch to high gear.

MAINTENANCE AND REPAIR


1. If you don't play for a long time, take out the battery.
2. Gently wipe the car with a damp cloth.
3. Do not put toys in places with high temperature, high tide and direct sunlight.
4. Do not put toys in water, it will damage the electronic components.

PRECAUTIONS

- Please pay attention to the polarity when installing or replacing the battery.
- Non-rechargeable batteries cannot be charged.
- Adult supervision is required when charging the rechargeable battery.
- Do not use old or new or different types of batteries.
- Pay attention to nearby signal interference during operation, otherwise it will affect the remote control distance.
- When the speed of the remote control car slows down, it means that the power of the car body is insufficient. Please charge the remote control car according to the above method.
- If the battery power of the remote control is low and the indicator light becomes dim or not bright, replace the battery with a new one.
- When not in use for a long time, please take out the battery in the remote control, turn the power switch of the remote control car to the "OFF" position, and take out the battery of the remote control car body.

TIPS

When the car is moving, please do not touch the four wheels of the remote control car with your hands, so as not to damage the remote control car.



Do not play on the side of the road or in dangerous places to prevent accidents.

Don't play with your RC car in the sinkhole.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.