

Model: H01-T

Installation Manual

• Thank you for choosing our products. Please read the instructions carefully before installation and keep it available for future maintenance or reference.

Content

Safety instructions — 01 Technical specification —————————————————————03 List of materials ————————————————————06 Technical drawing — 07 Parts identification — 08 Toilet installation —————————————————————09 Preparation — 12 Auto open/close lid _______13 Foot sensor — 14 1. Main unit care and maintenance 2. Filter maintenance 3. Spray nozzle care and maintenance 1. Power and water failure 2. Failure of remote control 3. Product unused for a period of time

IMPORTANT SAFEGUARDS

When using electrical products, especially when children are present, basic safety precautions should always be followed, including the following:

- 1. The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.
- 2. This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- 3. Children shall not play with the appliance.
- 4. Cleaning and user maintenance shall not be made by children without supervision.

READ ALL INSTRUCTIONS BEFORE USING



DANGER – To reduce the risk of electrocution:

- 1. Do not use while bathing.
- 2. Do not place or store product where it can fall or be pulled into a tub or sink.
- 3. Do not place in or drop into water or other liquid.
- 4. Do not reach for a product that has fallen into water. Unplug immediately.
- 5. Do not wash the main unit or electrical plug with water or detergent.
- 6. Do not handle the electrical plug with wet hands.
- 7. Never block the outlet of the air dryer.
- 8. Never disassemble, repair or modify this product.
- 9. During installation, disassembly, repair and maintenance of the product, the power plug must be switched off and water supply be shut off.



WARNING – To reduce the risk of burns, electrocution, fire, or injury to persons.

- 1. Close supervision is necessary when this product is used by, on, or near children or individuals with disabilities.
- 2. Use this product only for its intended use as described in this manual. Do not use attachments not recommended by the manufacturer.
- 3. Never operate this product if it has a damaged cord or plug, if it is not working properly, if it has been dropped or damaged, or dropped into water. Return the product to a service center for examination and repair.
- 4. Keep the cord away from heated surfaces.
- 5. Never use while sleeping or drowsy.
- 6. Never drop or insert any object into any opening or hose.
- 7. Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- 8. Connect this product to a properly grounded outlet only. See Grounding Instructions.
- 9. Do not throw cigarettes and other burning materials into toilet, otherwise it might cause fire.
- 10. This product is an electric appliance, so it must be placed far away from water and other liquid.
- 11. Do not lay the product on its side or upside down during the electrical circuit.
- 12. It is prohibited to use other electric appliances in the same socket.
- 13. It is forbidden to use the power extension or unstable loose outlet.
- 14. Do not reuse any existing water supply hoses, otherwise it might cause leakage, fire or electrical shock. Installation should include specified components and a new water supply hose.
- 15. For models with foam shield function, please do not put corrosive liquid in the foam shield, otherwise it may cause electric shock or burn.

IMPORTANT SAFETY INSTRUCTIONS

CAUTION – Indicates that failure to follow the instruction may cause body injury or property damage.

- 1. Do not install or use the product in wet places as steam room etc.
- 2. It is recommended to use water-proof electrical outlet which should be installed in a place where is not easily to get wet.
- 3. This product should be used with 110V-120V, 50/60Hz electrical current only, load current is at least 15A. Power plug must be equipped with ground fault circuit interrupter or ground fault electrical leakage protector or similar high sensitive, rapid type leakage switch (Rated sensitive current under 6mA).
- 4. When it thunders, it is strongly recommended to pull out the power plug.
- 5. Do not stand on ceramic toilet.
- 6. Ceramic toilet must install floor fixing bolts.
- 7. Do not stand on product unit, seat and lid.
- 8. Do not lean against the seat lid when using the product, to avoid damage.
- 9. This product is equipped with a soft-closing seat lid. Do not push the toilet seat closed, or damage may occur.
- 10. Do not use any caustic chemicals or scrubbing brush to clean this product.
- 11. Exposure to direct sunlight is prohibited.
- 12. Only use tap water or potable water, otherwise it may cause chafing.
- 13. Do not connect water supply to heater outlet. Make sure inlet water temperature is between 3~35°C/37.4~95°F.
- 14. When the room temperature is under zero degree, please drain the water tank, to avoid freezina.
- 15. Raise room temperature to prevent the toilet from damage due to freezing.
- 16. When moving the product from cold or wet environment into normal room temperature, wait for 2 hours until the condensation water is fully volatilized. Doing so can prevent the product from electrical short-circuit.
- 17. When not using the product over three(3) days, drain the water out of the toilet and pull the electrical plug from the wall outlet.
- 18. Stop using the product and shut off the power when product malfunctions. Call for professional service.
- 19. For models with the foam shield function, please do not run the foam shield function without the "foam agent", otherwise the service life of the foam shield may be shortened.

GROUNDING INSTRUCTIONS

This product should be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. This product is equipped with a cord having a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded.

DANGER – Improper use of the grounding plug can result in a risk of electric shock.

If repair or replacement of the cord or plug is necessary, do not connect the grounding wire to either flat blade terminal. The wire with insulation having an outer surface that is green with or without yellow stripes is the grounding wire.

This product is factory equipped with a specific electric cord and plug to permit connection to a proper electric circuit. Make sure that the product is connected to an outlet having the same configuration as the plug. No adapter should be used with this product. Do not modify the plug provided — if it will not fit the outlet, have the proper outlet installed by a qualified electrician. If the product must be reconnected for use on a different type of electric circuit, the reconnection should be made by qualified service personnel.

SAVE THESE INSTRUCTIONS

Technical specification

| Model | | H01-T |
|--------------------|--------------------------|---|
| Main Unit | Rated voltage | 110V-120V, 50/60Hz |
| | Rated power | 875W |
| | Water proof | IPX4 |
| | Power cord length | About 2.3m |
| Toilet | Flush volume | 1.6/1.1Gpf, 6.0L(full flush)/4.1L(half flush) |
| | Flushing mode | Siphonic jet |
| | Rough-in | 12 inches (305mm) |
| | Outlet outside diameter | ≤ 3.9 inches (≤ 100mm) |
| | Drainage method | S-trap |
| | Water pressure range | Minimum water pressure 0.08MPa, Maximum water pressure 0.8MPa |
| Cleaning device | Heating mode | Instant |
| | Heating power | 120V/1400W |
| | Water temperature | 6-level adjustment |
| | Water volume | 3-level adjustment |
| | Cleaning mode | Rear washing/Oscillating washing, Front washing/Oscillating washing |
| | Nozzle position | 5-level adjustment |
| | Water pressure protector | Pressure maintaining device, Automatic pressure relief device |
| | Anti-fouling device | Automatic nozzle cleaning, Anti-backflow device, Anti-syphon device, Filter device |
| | Safety device | Thermal fuse, Ground protection, Thermostat, Water temperature sensor, Over temperature protection, Leakage protection plug |
| Deodorization | Deodorization method | Photocatalyst-free |

| Drying device | Warm air volume | Over 0.2m³/min |
|--------------------|--|---|
| | Warm air temperature | 6-level adjustment |
| | Heating power | 230W |
| | Safety device | Thermal fuse, Thermostat, Leakage protection plug, Wind temperature sensor |
| Heated seat | Surface temperature | 6-level adjustment |
| | Heating power | 50W |
| | Burn protection | After 10 minutes of use, the seat temperature will automatically drop slowly to a low level |
| | Safety device | Seat sensor, Temperature sensor, Thermostat, Thermal fuse, Leakage protection plug |
| Caring device | Night light assembly | Intelligent, Always on, Always off |
| | User ID setting | To avoid interference when used by multiple users |
| | Automatic flushing | Automatic flushing after use |
| | Foam Shield function | Splash-proof and odor-proof can be realized |
| | Foot sensor open lid (optional) | Foot sensor open lid/seat can be realized |
| | Foot sensor flushing function (optional) | Foot sensor flushing |
| | Auto-open lid function (optional) | Auto-open lid function can be realized |
| Antibacterial site | | Seat, Nozzle |

Rated power: Under the condition of ambient temperature 23°C/73°F, water static pressure 0.18MPa±0.02MPa, water temperature 15°C/59°F, power toilet on, set water pressure, seat temperature, water temperature to the highest level in turn and perform one rear washing cycle.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTF:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.


However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help.

The remote control operates at 2.4 GHz frequency. The main unit performs corresponding function upon the signal from remote control.

The lid auto open sensor module operates at 24 GHz frequency. The module will sense movement and open the lid when approached. (Only for the product with lid auto opening/closing function)

List of materials



Main Unit



Remote Control Components



Sealing Flange




Rough-in Template



Installation Manual



Filling funnel





Three way angle valve



Mounting Kit

Technical drawing







- 1. The drawing is for reference only, and we reserve the right to modify the product appearance.
- 2. Product appearance is subject to change in kind.

Parts identification


Left side





Toilet installation


- Install the matching three-way angle valve
 - Mark the center line of the sewage outlet on the ground, and install a three-way angle valve at a suitable position on the wall according to the size of the toilet.




Note:

- 1. Please use the supplied angle valve when installing this toilet. Use of another angle valve not including a filter may result in blockages in the toilet and bidet waterways.
- 2. If replacing an existing angle valve, please contact a professional for installation.


Installation Method 1:




Installation Method 2:




- 2. Rough-in template installation
 - Align cardboard with the centerline of drain outlet.
 - Draw contour line according to cardboard.



- 3. Mounting bracket installation
 - Assemble the mounting bracket with bolts and then install them to the pre-installed flange plate on the ground and lock tight with nuts.



- 4. Ceramic toilet installation
 - Install a sealing flange into drain outlet.
 - Install ceramic toilet on the corresponding position.




Note:

- 1. Two people are required to carry the toilet.
- 2. Please clean up the drain outlet.
- 3. Please make sure ceramic toilet outlet sits perfectly on drain outlet.

5. Screw installation

- Put the screw through the fixing sleeve and then install it through the holes (on both sides of the toilet bowl) to the mounting bracket on the ground. Lock tight.
- Install the decorative cap on the fixing sleeve.



6. Connect the hoses

 Connect the water supply hose of the toilet tank and the water inlet hose of the toilet seat to the three-way angle valve as shown in the figure.

