







尺寸: 105*72mm

材质: 80g书写纸

印刷: AB双面印刷

折页: 左右风琴折, 再上下风琴折

A面

<p>Leadsail 2.4G WIRELESS KEYBOARD AND MOUSE SET</p>  <p>What's in box: 1.1×wireless keyboard 2.1×wireless mouse 3.1×USB nano receiver 4.1×User manual</p> <p>KF-29+TM-013 Ergonomic Design</p> <p>— 1 —</p>	<p>1. </p> <p>2.  Power switch Power LED USB Nano-receiver</p> <p>Open the battery cover at the bottom of the mouse. After confirming the two poles of the battery, insert the battery.</p> <p>— 2 —</p>	<p>3.  2pcs AA type batteries not included</p> <p>4.  ON/OFF button USB nano receiver</p> <p>Take the USB nano receiver from package and plug to your PC or laptop; your keyboard and mouse ready for use</p> <p>— 3 —</p>	<p>Mouse features: 1.Left Click Button 2.Right Click Button 3.Scroll Wheel 4.DPI Switch Button (DPI 800/1200/1600)</p>  <p>① Left Click button</p> <p>— 4 —</p> <p>Keyboard features:</p> <table border="0"><tr><td>1. Music player</td><td>4. Mute volume</td><td>7. Pause/Play</td><td>10. Mail</td></tr><tr><td>2. Decrease volume</td><td>5. Previous</td><td>8. Stop</td><td>11. Computer</td></tr><tr><td>3. Increase volume</td><td>6. Next</td><td>9. Navigate to internet home</td><td>12. Save as</td></tr></table>	1. Music player	4. Mute volume	7. Pause/Play	10. Mail	2. Decrease volume	5. Previous	8. Stop	11. Computer	3. Increase volume	6. Next	9. Navigate to internet home	12. Save as
1. Music player	4. Mute volume	7. Pause/Play	10. Mail												
2. Decrease volume	5. Previous	8. Stop	11. Computer												
3. Increase volume	6. Next	9. Navigate to internet home	12. Save as												
<p>Trouble shooting:</p> <p>1.Wireless mouse press DPI button to change the precision as your needs: Press DPI button the DPI is adjustable from 800 - 1200(default) - 1600.</p> <p>2.If the battery power is going to run up of the mouse, please replace it with 1 new AA type battery.</p> <p>3.Trying moving the keyboard and mouse more closer to USB nano receiver. (Distance Range:10m)</p> <p>4.If keyboard power LED flashes 3s and then goes out occasionally (Low power indicating) or no indicator light when turn on keyboard, please replace batteries with new one;or it will disconnect or response lagging.</p> <p>5.Plug your nano receiver to some other USB port of your PC or laptop.</p> <p>6.Put the AA battery(3pcs in total not included) into the mouse and keyboard in the right direction.</p> <p>7.Keyboard loses connection with nano receiver: If the power LED on the keyboard glows for 3s and then goes off, but your keyboard input is not recognized, it means the keyboard's connection to the nano-receiver has been lost. Please follow the instructions below step by step to reconnect: ① Turn off the keyboard ② Take the nano receiver out from USB port ③ Press the ESC +  (QWERTZ layout is ) keys at the same time, then slide the switch to the ON position, the power LED flashes for 5 seconds (the keyboard is activated). You have 5 seconds to plug and pair the receiver. ④ Plug the nano receiver back to the PC or laptop</p> <p>— 5 —</p>	<p>If the Power LED flashes for 3 seconds, pairing succeeds, and if it blinks for 5 seconds, the connection failed. Repeat the pairing twice or three times if the connection is not made on the first try.</p> <p>Very important: *Please make sure press  (QWERTZ layout is ) before you turn on keyboard; *The LED flashes for 5s for the search, please make sure you connect the receiver to the PC during the search. When the LED dies, it means that the search is finished. If no connection is established, repeat step ①~④ again. *Power LED flashes red only for 3s and then goes off and the keyboard does not respond. The keyboard function is normal. All you have to do is reconnect to the receiver. Please follow the connection procedure described above.</p> <p>8.If red sensor LED on button of mouse keep flashing but the cursor do not move, please try to pair it again as below steps: ① Pull out the receiver ② Turn off the mouse ③ Then slide the switch to ON position; mouse is in resourcing status ④ Plug the receiver back to pc or laptop</p> <p>— 6 —</p>	<p>This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.</p> <p>NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.</p> <p>If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: -- Reorient or relocate the receiving antenna. -- Increase the separation between the equipment and receiver. -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. -- Consult the dealer or an experienced radio/TV technician for help.</p> <p>The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction</p>													