

K2

User manual

Catalog


Compositiondescription.....	1~2
Usedescription.....	3
Poweronsettings.....	4~7
Faceregistration.....	8~11
Systemsettings.....	12~13

Composition description

1) Frame description




2) Interface description




Composition description

3) Productsize (mm) - Columnstyle



4) Productsize (mm) - Wallhangingstyle



Composition description



4) Use description

number	Module name	purpose
1	Infrared temperature measurement module	The body temperature is measured at a distance of 50cm ~ 80cm
2	1080p binocular camera	Collect face data, carry out living detection and identification offace
3	Green / red / white light	White light complements face recognition, red and green lights forewarn status
4	speaker	Play state content in language
5	network interface	Connect Ethernet to realize wired networking
6	Relay interface	Connect the switch, trigger the switch
7	USB2.0 Interface	Connect the mouse for local device and system operation
7	8-inch IPS screen	Human computer interaction between equipment and user


Warning: the equipment adopts the infrared temperature measurement principle. The equipment shall be avoided to be used outdoors as much as possible, and the direct light shall be avoided to the infrared temperature measurement module as much as possible, otherwise the effect of infrared temperature measurement will be interfered.

Power on settings


1) Access System settings-wifi page-select Wifi to connect-enter password to connect




2) 、 Go to system settings-bluetooth interface-select the bluetooth-connection you want




3) Power on settings network and deviceactivation



(WiFi network selection)




(Device activation)



Power on settings

1) Set server, company, community name, installation location and accessmode



Face registration


2) Face input of localdevice

(click the face mark in the lower right corner with the cursor)




Face registration

3) Select the gate settings - click "open facemanagement"



Face registration


4) Faceregistration




Face registration

5) Select single person registration & batch import face for registration


(Choose a single local photo)



Take photos, input name and card number for single registration




(Select batch import)



Batch registration: in batch registration mode, first use the U disk to name the employee's picture (such as "Zhang San. JPG") under a folder. Then click the batch import function on the face recognition machine. Select the picture folder under the U disk to import.


System settings

6) **Mask mode**(When the mask mode is on, the device recognizes the user without the mask, and prompts to wear the mask. The device flashes red status light to indicate early warning!)



System settings

6) **Stranger mode** (Turn on stranger mode, the device will flash red status light for unregistered face users to show early warning! Don't open the door!)



Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter