




RBWC-20030  
Thank you for purchasing a Rosewill Wireless Charging Stand.  
Please read the instruction manual before use and retain for future reference.

This charger is designed to quickly and easily charge your smart phone or Qi compatible device.




Dual coil design for vertical or horizontal charging

LED light displays standby or charging status

1

#### CONNECTING TO A USB-C CHARGER




1. Plug in your USB charger. (The USB charger is sold separately)
2. Plug the USB cable into the charger.
3. Connect the cable to the Wireless Charging Stand.

**Note:**

- The Wireless Charging Stand features intelligent power control, and can be safely stay in standby mode.
- Suggest to use PD Charger 18W or above.

2


#### CHARGING WITH YOUR LAPTOP



1. Plug the USB-C cable into your laptop's USB-C port and the other USB-C end into the Wireless Charging Stand.
2. The LED status indicator turns white when the charger is in Standby mode, and the charger will automatically turn off after 3 seconds. The indicator will stay on when the device is charging.

3


#### CHARGING WITH YOUR COMPUTER




1. Plug the USB cable into your computer's USB-C port and the other USB-C end into the Wireless Charging Stand.
2. The LED status indicator turns white when the charger is in Standby mode, and the charger will automatically turn off after 3 seconds. The indicator will stay on when the device is charging.

4

#### CHARGING YOUR DEVICES



If the device is placed incorrectly, the LED status indicator will start to flash – if this happens, adjust the position of the device until the LED status indicator stops flashing.



2 mobile phones or 1 mobile phone and 1 set of earbuds can be charged simultaneously.

#### Safety

1. Do not disassemble the charger or discard in a fire. Keep away from water and moisture as this can cause a short circuit.
2. Avoid dropping or damaging the charger – if the unit is damaged please discontinue use.
3. Do not use in excessively hot, humid or corrosive environments.
4. Do not place too close to credit cards or ID cards with magnetic strips to avoid damage to your cards or the charger.
5. Please keep at least 7.9 in (20 cm) distance between this device and medical devices such as pacemakers or cochlear implants, to avoid potential interference.
6. Please keep away from children.

The images in this manual are for illustration purposes only, and may differ from the final design.

5

#### SPECIFICATIONS

- Type-C Input: 5V/14.5V/20V 3A(Max)
- Type-C Output: 5V/1A(Max 5W)
- Wireless Output: 5V/1A(5W), 5V/1.5A(7.5W), 9V/1.1A(Max 10W)
- Frequency: 110 - 205 KHz
- Conversion: >72%
- Dimensions: 4.6 x 3.4 x 2.4 in (117 x 86 x 60 mm)

#### PACKAGE CONTENT

- Wireless Charging Stand
- x1 USB-C to USB-C Cable
- x1 USB-A to USB-C Cable
- User Manual

#### FCC STATEMENT

This device complies with part 15 and part 18 of the FCC Rules. Operation is Subject To the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not explicitly approved by the party responsible for compliance could void the user's authority to operate this equipment.

Note: this equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 and part 18 of the FCC Rules. These

limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. During the operation of device a distance of 15 cm surrounding the device and 20 cm above the top surface of the device must be respected.

This device complies with Part 18 of the FCC Rules. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Increase the separation between the equipment and any other radio device.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.



Technical Support Information: [techsupport@rosewill.com](mailto:techsupport@rosewill.com) 1-800-675-9885  
Please register your product at [www.rosewill.com](http://www.rosewill.com) for complete warranty information and support for your product.

RBWC-20030\_A

100mm

75mm

刀线

参考线

6