







PSD NVNT ax20 5240MHz Ant1




PSD NVNT ax20 5260MHz Ant1




PSD NVNT ax20 5280MHz Ant1




PSD NVNT ax20 5320MHz Ant1




PSD NVNT ax20 5500MHz Ant1




PSD NVNT ax20 5580MHz Ant1




PSD NVNT ax20 5700MHz Ant1




PSD NVNT ax20 5745MHz Ant1




PSD NVNT ax20 5785MHz Ant1




PSD NVNT ax20 5825MHz Ant1




PSD NVNT ax20 5180MHz Ant2




PSD NVNT ax20 5200MHz Ant2




PSD NVNT ax20 5240MHz Ant2




PSD NVNT ax20 5260MHz Ant2




PSD NVNT ax20 5280MHz Ant2




PSD NVNT ax20 5320MHz Ant2




PSD NVNT ax20 5500MHz Ant2




PSD NVNT ax20 5580MHz Ant2




PSD NVNT ax20 5700MHz Ant2




PSD NVNT ax20 5745MHz Ant2




PSD NVNT ax20 5785MHz Ant2




PSD NVNT ax20 5825MHz Ant2




PSD NVNT ax20 5180MHz Ant3




PSD NVNT ax20 5200MHz Ant3




PSD NVNT ax20 5240MHz Ant3




PSD NVNT ax20 5260MHz Ant3




PSD NVNT ax20 5280MHz Ant3




PSD NVNT ax20 5320MHz Ant3




PSD NVNT ax20 5500MHz Ant3




PSD NVNT ax20 5580MHz Ant3




PSD NVNT ax20 5700MHz Ant3




PSD NVNT ax20 5745MHz Ant3




PSD NVNT ax20 5785MHz Ant3




PSD NVNT ax20 5825MHz Ant3




PSD NVNT ax40 5190MHz Ant1




PSD NVNT ax40 5230MHz Ant1




PSD NVNT ax40 5270MHz Ant1




PSD NVNT ax40 5310MHz Ant1




PSD NVNT ax40 5510MHz Ant1




PSD NVNT ax40 5550MHz Ant1




PSD NVNT ax40 5670MHz Ant1




PSD NVNT ax40 5755MHz Ant1




PSD NVNT ax40 5795MHz Ant1




PSD NVNT ax40 5190MHz Ant2




PSD NVNT ax40 5230MHz Ant2




PSD NVNT ax40 5270MHz Ant2




PSD NVNT ax40 5310MHz Ant2




PSD NVNT ax40 5510MHz Ant2




PSD NVNT ax40 5550MHz Ant2




PSD NVNT ax40 5670MHz Ant2




PSD NVNT ax40 5755MHz Ant2




PSD NVNT ax40 5795MHz Ant2




PSD NVNT ax40 5190MHz Ant3




PSD NVNT ax40 5230MHz Ant3




PSD NVNT ax40 5270MHz Ant3




PSD NVNT ax40 5310MHz Ant3




PSD NVNT ax40 5510MHz Ant3




PSD NVNT ax40 5550MHz Ant3




PSD NVNT ax40 5670MHz Ant3




PSD NVNT ax40 5755MHz Ant3




PSD NVNT ax40 5795MHz Ant3




PSD NVNT ax80 5210MHz Ant1




PSD NVNT ax80 5290MHz Ant1




PSD NVNT ax80 5530MHz Ant1




PSD NVNT ax80 5610MHz Ant1




PSD NVNT ax80 5775MHz Ant1




PSD NVNT ax80 5210MHz Ant2




PSD NVNT ax80 5290MHz Ant2




PSD NVNT ax80 5530MHz Ant2




PSD NVNT ax80 5610MHz Ant2




PSD NVNT ax80 5775MHz Ant2




PSD NVNT ax80 5210MHz Ant3




PSD NVNT ax80 5290MHz Ant3




PSD NVNT ax80 5530MHz Ant3



PSD NVNT ax80 5610MHz Ant3



PSD NVNT ax80 5775MHz Ant3



8. Frequency Stability Measurement

8.1. Limit of Frequency Stability

Manufacturers of U-NII devices are responsible for ensuring frequency stability such that an emission is maintained within the band of operation under all conditions of normal operation as specified in the user's manual.


8.2. Measuring Instruments

The measuring equipment is listed in the section 3 of this test report.

8.3. Test procedures

- (1) To ensure emission at the band edge is maintained within the authorized band, those values shall be measured by radiation emissions at upper and lower frequency points, and finally compensated by frequency deviation as procedures below.
- (2) The EUT was operated at the maximum output power, and connected to the spectrum analyzer, which is set to maximum hold function and peak detector. The peak value of the power envelope was measured and noted. The upper and lower frequency points were respectively measured relatively 10 dB lower than the measured peak value.
- (3) The frequency deviation was calculated by adding the upper frequency point and the lower frequency point divided by two. Those detailed values of frequency deviation are provided in table below.

8.4. Test setup



8.5. Test result

Normal Temperature

Condition	Mode	Frequency (MHz)	Antenna	Measured Frequency (MHz)	Frequency Error (Hz)	Deviation (ppm)	Limit (ppm)	Verdict
NTLV	a	5180	Ant1	5179.98	-20000	-3.86	25	Pass
NTNV	a	5180	Ant1	5179.94	-60000	-11.58	25	Pass
NTHV	a	5180	Ant1	5179.98	-20000	-3.86	25	Pass
NTLV	a	5200	Ant1	5199.96	-40000	-7.69	25	Pass
NTNV	a	5200	Ant1	5199.96	-40000	-7.69	25	Pass
NTHV	a	5200	Ant1	5199.94	-60000	-11.54	25	Pass
NTLV	a	5240	Ant1	5239.98	-20000	-3.82	25	Pass
NTNV	a	5240	Ant1	5239.96	-40000	-7.63	25	Pass
NTHV	a	5240	Ant1	5239.96	-40000	-7.63	25	Pass
NTLV	a	5260	Ant1	5259.98	-20000	-3.8	25	Pass
NTNV	a	5260	Ant1	5259.96	-40000	-7.6	25	Pass
NTHV	a	5260	Ant1	5259.94	-60000	-11.41	25	Pass
NTLV	a	5280	Ant1	5279.92	-80000	-15.15	25	Pass
NTNV	a	5280	Ant1	5279.92	-80000	-15.15	25	Pass
NTHV	a	5280	Ant1	5279.96	-40000	-7.58	25	Pass
NTLV	a	5320	Ant1	5319.98	-20000	-3.76	25	Pass
NTNV	a	5320	Ant1	5319.96	-40000	-7.52	25	Pass
NTHV	a	5320	Ant1	5319.94	-60000	-11.28	25	Pass
NTLV	a	5500	Ant1	5499.98	-20000	-3.64	25	Pass
NTNV	a	5500	Ant1	5499.96	-40000	-7.27	25	Pass
NTHV	a	5500	Ant1	5499.96	-40000	-7.27	25	Pass
NTLV	a	5580	Ant1	5579.96	-40000	-7.17	25	Pass
NTNV	a	5580	Ant1	5579.96	-40000	-7.17	25	Pass
NTHV	a	5580	Ant1	5579.94	-60000	-10.75	25	Pass
NTLV	a	5700	Ant1	5699.94	-60000	-10.53	25	Pass
NTNV	a	5700	Ant1	5699.96	-40000	-7.02	25	Pass
NTHV	a	5700	Ant1	5699.94	-60000	-10.53	25	Pass
NTLV	a	5745	Ant1	5744.92	-80000	-13.93	25	Pass
NTNV	a	5745	Ant1	5744.92	-80000	-13.93	25	Pass
NTHV	a	5745	Ant1	5744.96	-40000	-6.96	25	Pass
NTLV	a	5785	Ant1	5784.96	-40000	-6.91	25	Pass
NTNV	a	5785	Ant1	5784.94	-60000	-10.37	25	Pass
NTHV	a	5785	Ant1	5784.94	-60000	-10.37	25	Pass
NTLV	a	5825	Ant1	5824.96	-40000	-6.87	25	Pass
NTNV	a	5825	Ant1	5824.94	-60000	-10.3	25	Pass
NTHV	a	5825	Ant1	5824.96	-40000	-6.87	25	Pass
NTLV	a	5180	Ant2	5179.96	-40000	-7.72	25	Pass

NTNV	a	5180	Ant2	5179.96	-40000	-7.72	25	Pass
NTHV	a	5180	Ant2	5179.96	-40000	-7.72	25	Pass
NTLV	a	5200	Ant2	5199.96	-40000	-7.69	25	Pass
NTNV	a	5200	Ant2	5199.98	-20000	-3.85	25	Pass
NTHV	a	5200	Ant2	5199.98	-20000	-3.85	25	Pass
NTLV	a	5240	Ant2	5239.96	-40000	-7.63	25	Pass
NTNV	a	5240	Ant2	5239.94	-60000	-11.45	25	Pass
NTHV	a	5240	Ant2	5239.96	-40000	-7.63	25	Pass
NTLV	a	5260	Ant2	5259.96	-40000	-7.6	25	Pass
NTNV	a	5260	Ant2	5259.94	-60000	-11.41	25	Pass
NTHV	a	5260	Ant2	5259.96	-40000	-7.6	25	Pass
NTLV	a	5280	Ant2	5279.96	-40000	-7.58	25	Pass
NTNV	a	5280	Ant2	5279.98	-20000	-3.79	25	Pass
NTHV	a	5280	Ant2	5279.94	-60000	-11.36	25	Pass
NTLV	a	5320	Ant2	5319.96	-40000	-7.52	25	Pass
NTNV	a	5320	Ant2	5319.96	-40000	-7.52	25	Pass
NTHV	a	5320	Ant2	5319.96	-40000	-7.52	25	Pass
NTLV	a	5500	Ant2	5499.94	-60000	-10.91	25	Pass
NTNV	a	5500	Ant2	5499.96	-40000	-7.27	25	Pass
NTHV	a	5500	Ant2	5499.96	-40000	-7.27	25	Pass
NTLV	a	5580	Ant2	5579.94	-60000	-10.75	25	Pass
NTNV	a	5580	Ant2	5579.96	-40000	-7.17	25	Pass
NTHV	a	5580	Ant2	5579.96	-40000	-7.17	25	Pass
NTLV	a	5700	Ant2	5699.92	-80000	-14.04	25	Pass
NTNV	a	5700	Ant2	5699.96	-40000	-7.02	25	Pass
NTHV	a	5700	Ant2	5699.94	-60000	-10.53	25	Pass
NTLV	a	5745	Ant2	5744.96	-40000	-6.96	25	Pass
NTNV	a	5745	Ant2	5744.96	-40000	-6.96	25	Pass
NTHV	a	5745	Ant2	5744.9	-100000	-17.41	25	Pass
NTLV	a	5785	Ant2	5784.94	-60000	-10.37	25	Pass
NTNV	a	5785	Ant2	5784.94	-60000	-10.37	25	Pass
NTHV	a	5785	Ant2	5784.96	-40000	-6.91	25	Pass
NTLV	a	5825	Ant2	5824.96	-40000	-6.87	25	Pass
NTNV	a	5825	Ant2	5824.96	-40000	-6.87	25	Pass
NTHV	a	5825	Ant2	5824.94	-60000	-10.3	25	Pass
NTLV	a	5180	Ant3	5179.98	-20000	-3.86	25	Pass
NTNV	a	5180	Ant3	5179.96	-40000	-7.72	25	Pass
NTHV	a	5180	Ant3	5179.96	-40000	-7.72	25	Pass
NTLV	a	5200	Ant3	5199.94	-60000	-11.54	25	Pass
NTNV	a	5200	Ant3	5199.98	-20000	-3.85	25	Pass
NTHV	a	5200	Ant3	5199.98	-20000	-3.85	25	Pass
NTLV	a	5240	Ant3	5239.98	-20000	-3.82	25	Pass
NTNV	a	5240	Ant3	5239.94	-60000	-11.45	25	Pass

NTHV	a	5240	Ant3	5239.96	-40000	-7.63	25	Pass
NTLV	a	5260	Ant3	5259.98	-20000	-3.8	25	Pass
NTNV	a	5260	Ant3	5259.96	-40000	-7.6	25	Pass
NTHV	a	5260	Ant3	5259.96	-40000	-7.6	25	Pass
NTLV	a	5280	Ant3	5279.96	-40000	-7.58	25	Pass
NTNV	a	5280	Ant3	5279.94	-60000	-11.36	25	Pass
NTHV	a	5280	Ant3	5279.98	-20000	-3.79	25	Pass
NTLV	a	5320	Ant3	5319.98	-20000	-3.76	25	Pass
NTNV	a	5320	Ant3	5319.94	-60000	-11.28	25	Pass
NTHV	a	5320	Ant3	5319.94	-60000	-11.28	25	Pass
NTLV	a	5500	Ant3	5499.96	-40000	-7.27	25	Pass
NTNV	a	5500	Ant3	5499.96	-40000	-7.27	25	Pass
NTHV	a	5500	Ant3	5499.98	-20000	-3.64	25	Pass
NTLV	a	5580	Ant3	5580	0	0	25	Pass
NTNV	a	5580	Ant3	5579.94	-60000	-10.75	25	Pass
NTHV	a	5580	Ant3	5579.94	-60000	-10.75	25	Pass
NTLV	a	5700	Ant3	5699.94	-60000	-10.53	25	Pass
NTNV	a	5700	Ant3	5699.94	-60000	-10.53	25	Pass
NTHV	a	5700	Ant3	5699.98	-20000	-3.51	25	Pass
NTLV	a	5745	Ant3	5744.94	-60000	-10.44	25	Pass
NTNV	a	5745	Ant3	5744.98	-20000	-3.48	25	Pass
NTHV	a	5745	Ant3	5744.96	-40000	-6.96	25	Pass
NTLV	a	5785	Ant3	5784.94	-60000	-10.37	25	Pass
NTNV	a	5785	Ant3	5784.94	-60000	-10.37	25	Pass
NTHV	a	5785	Ant3	5784.98	-20000	-3.46	25	Pass
NTLV	a	5825	Ant3	5825	0	0	25	Pass
NTNV	a	5825	Ant3	5825	0	0	25	Pass
NTHV	a	5825	Ant3	5825	0	0	25	Pass
NTLV	n20	5180	Ant1	5179.98	-20000	-3.86	25	Pass
NTNV	n20	5180	Ant1	5179.96	-40000	-7.72	25	Pass
NTHV	n20	5180	Ant1	5179.94	-60000	-11.58	25	Pass
NTLV	n20	5200	Ant1	5199.96	-40000	-7.69	25	Pass
NTNV	n20	5200	Ant1	5199.96	-40000	-7.69	25	Pass
NTHV	n20	5200	Ant1	5199.94	-60000	-11.54	25	Pass
NTLV	n20	5240	Ant1	5239.94	-60000	-11.45	25	Pass
NTNV	n20	5240	Ant1	5239.96	-40000	-7.63	25	Pass
NTHV	n20	5240	Ant1	5239.98	-20000	-3.82	25	Pass
NTLV	n20	5260	Ant1	5259.94	-60000	-11.41	25	Pass
NTNV	n20	5260	Ant1	5259.94	-60000	-11.41	25	Pass
NTHV	n20	5260	Ant1	5259.96	-40000	-7.6	25	Pass
NTLV	n20	5280	Ant1	5279.96	-40000	-7.58	25	Pass
NTNV	n20	5280	Ant1	5279.94	-60000	-11.36	25	Pass
NTHV	n20	5280	Ant1	5279.94	-60000	-11.36	25	Pass