


CW301 Instruction manual




3IN1 FAST WIRELESS CHARGER

Product Introduction




- 1. 10W Wireless Charging Area for Phones
- 2. 5W Wireless Charging Area for Earphones
- 3. Wireless Charging Module for Watches
- 4. Status Indicators



- 5. Type-C Power Supply Port
- 6. Power Indicator


Steps for Usage

1. Simply connect the Wireless Charging Module for Watches to the pogo pin power supply port to start charging.




2. Connect external power supply to power on

2.1 Use an adapter that supports 9V and connect it to the CW301 wireless charger via the Type-C power cable.



2.2 The charger will automatically power on when connected to a power source, with the bottom power indicator illuminating in permanent red.


Remarks: The power cable should be properly inserted into place to prevent loosening or disconnecting, otherwise it may fail to power on the device. It's recommended to use an adapter that supports 9V, otherwise, a regular adapter may fail to charge or charge at proper speed when initiating quick charge or charging multiple devices.



3. Charging description

- 3. 1. Place your phone in the 10W Wireless Charging Area, align the center of the phone's wireless charging area with that of the charger, and the Status Indicator will illuminate and stay on to indicate that it's charging normally.
- 3.2. Place your earphone in the 5W Wireless Charging (Slot) Area, align the center of the earphone's wireless charging area with that of the charger, and the Status Indicator will illuminate and stay on to indicate that it's charging normally.
- 3.3. Place your watch on the installed Wireless Charging Module for Watches, the watch will be magnetically attached, and the watch display will show a charging icon to indicate that it's charging normally.

Remarks: Do not attach any metal sheet at the back of your phone. It's recommended to remove your phone's protective case before charging to avoid any potential interference.



4. Indicators description

- 4.1. Equipped with 1 red Power Indicator, and 2 blue Status Indicators respective to the 5W Charging Area and 10W Charging Area.
- 4.2. When powered on, the red Power Indicator will illuminate and stay on, while the blue Status Indicators will flash 3 times then go off.
- 4.3. The blue Status Indicator will stay off when not charging or fully charged.
- 4.4. The blue Status Indicator will stay on during charging.
- 4.5. The blue Status Indicator will keep flashing when there is any charging abnormality.

Name	Wireless Charger	Model	CW301
Product size	175X100X14(mm)	Power Supply Port	≤5mm
Input	9V 2A	Maximum output power	18W

Maximum H-Field: 17. 43dBuA/m@3m

Frequency Range: 110-205 kHz

FCC WARNING STATEMENT

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment must be installed and operated in accordance with provided instructions and the antenna(s) used for this transmitter must be installed to provide a separation distance of at least 15 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter. End-users and installers must be provided with antenna installation instructions and transmitter operating conditions for satisfying RF exposure compliance.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.