

# **New Intelligent Folding Golf Trolley**

## **Operating instructions**

## **Table of Contents**

- 1. The contraction and folding of the Golf Trolley**
- 2. Introduction of umbrella holder, battery and display screen**
- 3. Use of Remote Control**


## 1. The contraction and folding of the Golf Trolley

### 1.1 Contraction of the telescopic pole

Contraction of the longitudinal telescopic pole is shown in the figure:

- ① Open the lock clasp,
- ② Pull the upper pole down to the bottom,
- ③ Close the lock clasp. The same method for the horizontal telescopic pole.


Method of expansion the telescopic pole, and vice versa.



## 1.2 Folding of armrests and poles

Folding of the armrest is shown in the figure:

- ① Open the locking clasp,
  - ② Rotate the armrest bar downward,
  - ③ Close the locking clasp. The same method for folding the pole.
- Method of unfolding the armrests and poles, and vice versa.




### 1.3 Folding of auxiliary wheel legs



Folding the auxiliary leg is shown in the figure.:

- ① Move the lock clasp backwards,
- ② Turn the auxiliary wheel leg to the inside,
- ③ Close the lock clasp.


Method of unfolding the auxiliary wheel legs, and vice versa.



**1.4 Golf trolley are shown below before and after folding.**



## 2. Introduction of umbrella holder, battery and display screen




### 2.1 Umbrella holder

It can be used to place and fix the parasol, and the direction can be adjusted by the knob.

### 2.2 Battery

It can be removed and installed by pulling. There are power button, USB interface and DC port. The USB interface is used for phone charging, and the DC port is used for battery charging.


### 2.3 Display Screen



- ① Bluetooth: Display Bluetooth connection status
- ② Speed: Display the running speed of the charter
- ③ Camera: Display the status of the camera function
- ④ Company Logo
- ⑤ Battery: Display battery remaining
- ⑥ Setting: Display when mobile phone changes the parameters of the charter
- ⑦ Miles: Display the mileage of the charter
- ⑧ Remote control: Display the connection status of the remote control



### 3. Use of Remote Control



## Remote Control

There are four buttons on the remote control: HOME, Direction, Left and Right.

**HOME button:** Long press to turn on/off the remote control

**Direction button:** Direct the charter to move forward, backward, left or right

**Left button:** Switch the charter to automatic follow state

**Right button:** Set the automatic lock state of the charter or enable the camera function

FCC ID: 2AX8W-CH-1

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction