

# Reference Size for Different Dogs

Size	Neck Girth (IN)	Chest Girth (IN)	Back Length (IN)	Weight (LBS)	Breed
<b>X-Small</b>	7.8 - 8.6	9.8 - 11.8	7.4	1 - 10	Chihuahua, Yorkshire, Terrier
<b>Small</b>	7.8 - 9.4	11.4 - 14.1	9.0	11 - 25	Poodle, Pomeranian
<b>Medium</b>	9.0 - 11.0	13.7 - 16.5	11.0	26 - 40	Shih Tzu, Maltese Dog
<b>Large</b>	10.6 - 12.2	16.1 - 18.5	12.2	41 - 70	Miniature Schnauzer, Pekingese
<b>Large</b>	11.8 - 13.3	18.1 - 20.8	13.7	71 - 90	English Cocker Spaniel
<b>Large</b>	12.9 - 14.5	20.4 - 23.2	15.7	91 - 110	Beagle
<b>X-Large</b>	16.9 - 18.9	29.9 - 33.0	23.6	N/A	Husky
<b>X-Large</b>	18.5 - 20.4	34.6 - 38.1	23.6	N/A	Labrador Retriever
<b>X-Large</b>	20.4 - 24.4	36.2 - 39.3	27.5	N/A	Golden Retriever, Old English Sheepdog

Transmitter: 3.7V 300mAH LIP  
Receiver: 3.7V 400mAH LIP

Made in China

Read Full User Manual Before Use!



**DOG**  
**TRAINING COLLAR**

More Effective and Safer Training Collar  
v Dogs with Our Advanced Technology

# Important Safety Information

## ⚠️ **WARNING:**

Not for use with aggressive dogs. Do not use this Product if your dog is aggressive, or if your dog is prone to aggressive behavior. Aggressive dogs can cause severe injury and even death to their owner and others. If you are unsure whether this product is appropriate for your dog, please consult your Veterinarian or certified trainer.

## ⚠️ **CAUTION:**

Safety during on-leash training. It is vitally important that you and your dog remain safe while learning during on-leash training. Your dog should be on a strong leash, long enough for him to attempt to chase an object, but short enough for him not to reach a road or other unsafe area. You must also be physically strong enough to restrain your dog when he tries to chase.

Risk of skin damage. Please read and follow the instructions in this manual. Proper fit of the collar is important. A collar worn for too long or made too tight on the pet's neck may cause skin damage. Ranging from redness to pressure ulcers; this condition is commonly known as bed sores.

- Avoid leaving the collar on the dog for more than 12 hours per day.
- When possible re-position the collar on the pet's neck every 1 to 2 hours.
- Check the fit to prevent excessive pressure; follow the instructions in this manual.
- Never connect a leash to the electronic collar; it will cause excessive pressure on the contacts.
- Never connect a leash to the electronic collar; it will cause excessive pressure on the contacts.
- When using a separate collar for a leash, don't put pressure on the electronic collar.


- Wash the dog's neck area and the contacts of the collar weekly with a damp cloth.
- Examine the contact area daily for signs of a rash or a sore.
- If a rash or sore is found, discontinue use of the collar until the skin has healed.
- If the condition persists beyond 48 hours, see your veterinarian.

These steps will help keep your pet safe and comfortable. Millions of pets are comfortable while they wear stainless steel contacts. Some pets are sensitive to contact pressure. You may find after some time that your pet is very tolerant of the collar. If so, you may relax some of these precautions. It is important to continue daily checks of the contact area. If redness or sores are found, discontinue use until the skin has fully healed.


# Table of Contents

Components	4
How the System Works	5
Key Features	6
Definition of the Product	7
Operating Guide	
• Charging the Device	10
• How to use the Dog Training Collar	12
• How to Syncing the Remote Transmitter & Collar Receiver	13
• How to Test the Functions	14
• How to Fit the Collar Receiver	15
• How to Find the Best Vibration/Shock Level for Your Pet	17
• How to Maximize the Distance	18
General Training Guide	19
Frequently Asked Questions	20
Trouble Shooting	21
FCC	22
Reference Size for Different Dogs	23


# Components



Remote Transmitter



Receiver Collar



Test Bulb




Steel Probe x 4



Silicone Covers x 4



USB Cable



Strap



User Manual

# How the System Works

The Dog Training Collar is easy to use with an advanced digital display that tells you exactly what level of stimulation you are using.

This Dog Training Collar assists you in controlling your pet without a leash in a designed remote range. At the push of a button, your remote sends a signal activating your dog's Collar Receiver. He receives a safe but annoying stimulation. He'll quickly learn the association between his behavior and your correction; in no time, you'll have a better-behaved pet. The Dog Training Collar has been proven safe, comfortable, and effective for both small and large dog breeds.

Using the Remote Trainer consistently and correctly, any basic obedience commands can be taught and many misbehaviors that your pet exhibits can be corrected.

## Safety Tips


This product is not intended for use on dogs under 6 months old or less than 8 pounds. This product must NOT be used on aggressive dogs. If you are unsure if this product is appropriate for your pet, please consult your veterinarian or a certified trainer.

# Key Features

1. Rechargeable Remote Transmitter and Collar Receiver
2. Waterproof Collar Receiver
3. LCD display with backlight screen for night using
4. Standard Tone
5. 8 intensity levels of vibrations
6. 16 intensity levels of static shocks
7. Three channels:  
Private Channel A, Channel B & Public Channel A+B
8. Security keypad lock
9. Independent buttons for tone, vibration and static shock.

# Definition of the Product

## Remote Transmitter



**LCD Screen:** Display the channel, intensity and battery fuel gauge.

### Channel Select / Lock Button

- Press the button to select Channel A, Channel B or public channel A+B.
- Press and hold the button to Lock or Unlock the intensity level of vibration or shock.

### Level Up/Down Button

- Set the level of Static Shock and Vibration.  
(WARNING: ALWAYS BEGIN WITH A LOW LEVEL SETTING IN THE INITIAL TRAINING STAGES.)
- If you want to set the level of vibration or static shock, please press the corresponding button first. The corresponding icon show on the display will flash 2 times. Now you can adjust the level by pressing the Up/Down button.


**Tone Button:** When it is pressed, the Collar Receiver will give a warning beep.

**Vibration Button:** When it is pressed, the Collar Receiver will vibrate, levels can be adjusted from 0 to 8 by pressing the Up/Down Button after pressing the Vibration Button.


**Shock Button:** When it is pressed, the Collar Receiver will issue the shock. Static shock levels can be adjusted from 0 to 16 by pressing the Up/Down Button after pressing the Shock Button.

**Charging Hole:** For remote transmitter charging.

## Collar Receiver



Power ON/OFF /  
Encode Button



**Notes:** The hexagon hole on the Test Bulb can be used to fasten or unfasten the Probes to contact points.

### Power ON/OFF / Encode Button:

- Turn On/Off the Collar Receiver.
- Hold it for a 3 seconds to encode the receiver UNDER THE SHUT POWER OFF STATE.

### LED Indicator:

- In "Standby" status, the LED light will flash green every 5 seconds, will flash red when the battery at the low power mode (please charge it ASAP).
- When Charging, the LED light is red. It will turns to green when fully charged.

### Charging Port:

 For Collar Receiver charging.

**Rubber Cover:** After completion of charging. Please put the cover in place to safe guard the internal unit from dust and water.

**Conductive Probe Cover:** Avoid the injury to the dog's skin because of the friction of metal contact point.

**Contact Points:** Deliver vibration and static shock (with Stainless Steel Probe).

## Step 1 Charging the Device

The Dog Training Collar use Lithium-Polymer batteries. DO NOT charge the device near any flammable substances. Fully charge the Remote Transmitter and Collar Receiver before use.

Charge the Dog Training Collar if:

- There is only 1 battery level bar left on the Remote Transmitter LCD display.
- The indicator light on the Collar Receiver will not come on.

### Charge the Remote Transmitter


1. Connect the USB cable connectors to the charging jack on Remote Transmitter.
2. Connect the USB cable port to the power adapter, power band or your PC.
3. The battery icon on the LCD display will scroll when charging.
4. Charge the transmitter at least 2 hours for first charge or until indication that charging is complete.
5. When charging is complete, the battery capacity indicator will not flash any more.
6. When battery capacity "████" indicator is empty, please charge it ASAP.

**Note:** Approximate battery life is 6 months after fully charged, depending on frequency of use.

## Charge the Collar Receiver

1. Lift the rubber cover on the Collar Receiver charging jack.
2. Connect the USB cable connectors to the charging jack on Collar Receiver.
3. Connect the USB cable port to the power adapter, power band or your PC.
4. The red LED light on the Collar Receiver will flash RED.
5. Charge the Collar Receiver for at least 3 hours for the first charge or until indication that charging is complete.
6. After the Collar Receiver has been fully charged, the LED light will turn solid GREEN.
7. When charging is finished, put the rubber cover in place to keep the internal unit from dust and water.
8. Please charging the Collar Receiver immediately when the LED light flash RED.

**Note:** Turn the Receiver Collar off when it is not in use. Approximate battery life is 1 week after fully charged, depending on frequency of use.



### Warning:

Please use those with 5V output voltage. The output voltage information is usually described on the surface of power adapter. Power adapter with output voltage over 5V may cause damage to the training collar.

## Step 2 How to use the Dog Training Collar

### Remote Transmitter:

1. Press any button to turn ON the Remote Transmitter.
2. Press the Channel/Lock button to select Channel A , Channel B or Public Channel A+B .
2. Press Up/Down buttons to adjust the intensity level of vibration or static shock.
3. A/B channels indicates either channel A, channel B or channel A+B on the transmitter. Select one channel for use with one Collar Receiver. If encoded at the public channel A+B, you can control the Collar Receiver at any of channels.
4. The LCD screen will go to sleep if no use in 30 seconds, to conserve battery power. You can simply press any button to activate the transmitter.
5. Press and hold the Channel/Lock button to lock or unlock the intensity level of vibration or shock

### Collar Receiver:

1. To turn On the Collar Receiver, press the Power button, a beep sound will heard, the LED light will flash green every 7 seconds.
2. To turn Off the Collar Receiver, press the Power button, 2 beeps sound will heard. The indicating light will turn off.

## Step 3 How to Syncing the Remote Transmitter & Collar Receiver

1. Press any button on the transmitter to activate it.
2. Select Channel A , B  or Public Channel A+B .
3. Power Off the Collar Receiver by press the Power  button on Collar. (a beep power On, 2 beeps power Off.)
4. Press Power  button afresh and **HOLD** it for 3 seconds, the LED will start to flash green quickly for 10 seconds.
5. Now you can hear the first beep from the Collar Receiver, and then press any of the command button (tone, shock or vibration) of the Remote Transmitter before the green light on the receiver stop flashing quickly.
6. You will hear the second beep from the Collar Receiver, which signifies that the transmitter and the receiver have been synced.
7. To sync the Remote Transmitter and the second Collar Receiver, repeat step 2 through 6.
8. Please be sure to choose the other channel.


**Note:** According to the factory default settings, when the Collar Receiver has been turned on the syncing should be completed within 10 seconds, thereby you have to press the COMMAND BUTTON in good time or press it at least within 10 seconds. Please DO NOT try to sync the transmitter with the two Collar Receivers (if any) at the same time.




Channel A



Channel B



Public Channel A+B  
(Remote 2 Receiver at the same time)




Press and hold for 3 seconds

## Step 4 How to Test the Functions

### Test the static shock function

- Put the test-light on the contact point of the Collar Receiver. Turn on the Remote Transmitter, press the Up/Down to adjust the intensity level.
- Press shock  button and the bulb will flash, signifying that the Shock function works.
- Please make sure the Shock level is above 4 when testing the function to see more clearly.

**Note:** If wanting to test the shock function on yourself, please ensure your finger or hand is across both contact points to ensure the connection is complete. Otherwise, user will feel no stimulation.



### Test the vibration function

- Turn on the Remote Transmitter, press the Vibration  button first then press the Up/Down button to adjust the vibration level.
- Press the Vibration button on the Remote Transmitter, the Collar Receiver will vibration, signifying the Vibration function works.

### Test the beep function

- Turn on the Remote Transmitter.
- Press the Tone  button, the Collar Receiver will beep, signifying the Tone function works.

#### Note:


1. To save power, the transmitter will go into Standby mode if there's no operation in 5 minutes. You can press any button on transmitter to activate it and its screen will display.
2. The Collar Receiver will go into Sleep Mode if there is no operation for 2 minutes and The LED stop flashing. Will be activated when receiving the command (shock, vibration or tone) from the transmitter.

## Step 5 How to Fit the Collar Receiver

**Important:** The proper fit and placement of your Collar Receiver is important for effective training. The Contact Points must have direct contact with your pet's skin on the underside of his neck, or he cannot feel the static shock.


To assure a proper fit, please follow these steps:

1. Make sure that the Collar Receiver is turned off.
2. Have your pet standing comfortably (Fig 1).
3. Place the Collar Receiver on your dog's neck close to the ears. Center the Contact Points underneath your dog's neck, touching the skin (Fig 2).
- Note:** It is sometimes necessary to trim the hair around the Contact Points to make sure that contact is consistent.
- CAUTION: Do not shave the pet's neck as this may increase the risk of skin irritation.**
4. The Collar Receiver should fit snugly, yet loose enough to allow one finger to fit between the strap and your pet's neck (Fig 3).
5. Allow your pet to wear the collar for several minutes then recheck the fit. Check the fit again as your pet becomes more comfortable with the Collar Receiver.




### 6. Re-thread the Collar Receiver:

Attached the strap to the Collar Receiver. Take out the slide buckle from the collar first. Follow the steps instructed to thread the collar.



### 7. Trim the collar as follows (Fig 4):

- a. Mark the desired length of the collar with a pen. Allow for growth if your pet is young or grows a thick winter coat.
- b. Remove the Collar Receiver from your pet and cut off the excess.
- c. Before placing the Collar Receiver back onto your pet, seal the edge of the cut collar by applying a flame along the frayed edge.



## Step 6 How to Find the Best Vibration / Shock Level for Your Pet

**Important:** Always start at the lowest level and work your way up. The Dog Training Collar has 8 Levels for vibration and 16 Levels for static shock, with level 1 being the lowest level and level 8 of vibration and level 16 of shock being the highest. This allows you to choose the stimulation level that is best for your pet. Once you have placed the Collar Receiver on your pet, it is time to find the stimulation Level that is best for him. This is called the Recognition Level. A slight change in your pet's behavior, such as looking around in curiosity, scratching at his collar, or flicking his ears, indicates the Recognition Level that is best for him.

Follow the steps below to find your pet's recognition Level:


1. Starting at Level 1 on the Digital Display, press the Vibration/Shock Button.
2. If your pet shows no reaction, repeat the Stimulation Level several times before moving up to the next level.
3. YOUR PET SHOULD NOT VOCALIZE OR PANIC WHEN RECEIVING STIMULATION. IF THIS HAPPENS, THE STIMULATION LEVEL IS TOO HIGH AND YOU NEED TO GO BACK TO THE PREVIOUS LEVEL AND REPEAT THE PROCESS
4. Move up through the stimulation Levels until your pet reliably responds to the stimulation.
5. If your pet continues to show no response at the highest Level, check the fit of the Collar Receiver. If your pet has long or thick hair, please use the longer set of Contact Points in package. Then go back to #1 and repeat the process.

If this still does not yield any results, your pet's hair will need to be trimmed around the Contact completing all of these steps, your dog still does not indicate he is feeling the stimulation, please contact our customer service.

## Step 7 How to Maximize the Distance

Terrain, weather, vegetation, transmission from other radio devices, and other factors will affect the maximum range.

Hold the Remote Transmitter in a horizontal position away from your body to achieve optimum range. For Maximum signal strength, keep the device properly charged.



\* Avoid touching the antenna or the range may decrease substantially.

## General Tips

- Eliminate one misbehavior or teach one obedience command at a time. If you move too fast with training, your pet may become confused.
- Be consistent. Correct your pet every time he misbehaves.
- Unless you can supervise him, it is recommended that you restrict your pet from situations in which he has a history of misbehaving. However, setting up a situation as a training session can dramatically improve your chances of success.
- If your pet reacts to the beeps by hiding or acting fearful, redirect his attention to a simple and appropriate behavior, such as the "sit" command.
- Pets should be at least 6 months old before using the Trainer.
- Only let responsible family members use the Trainer. It is not a toy!
- Other pets in hearing range will be affected by the training beeps. Therefore, training sessions should be conducted out of hearing range of other pets.

**CAUTION:** Never use the Dog Training Collar to correct or eliminate any form of aggressive behavior. We recommend you contact your local veterinarian or professional trainer to determine if your pet might be aggressive. See page 1 for more information.

## *Is the Stimulation safe for my pet?*

**ANS:** While the Stimulation is unpleasant, it is harmless to your pet. Electronic training devices require interaction and training from the owner to achieve desired results.

## *How old does my pet have to be before using the Dog Training Collar?*

**ANS:** Your pet should be able to recognize basic obedience commands such as "Sit" or "Stay". Pets should be at least 6 months old before using the Trainer.

## *Once my pet is trained and has been obeying my commands, will he have to continue to wear the Collar Receiver?*

**ANS:** Probably not. You may need to reinforce training with the Receiver Collar from time to time.

## *Is the Collar Receiver waterproof?*

**ANS:** Yes. Collar Receiver is IPX7 waterproof, but make sure to keep the area dry when charging.

**Notes:** Remote Transmitter is not waterproof.

## *Why sometimes I get short remote range with the Dog Training Collar?*

**ANS:** The range of the Dog Training Collar will vary according to terrain, weather, vegetation, as well as transmission from other radio devices. See "How the System Works" for tips on maximizing your range.

## *How long can I continuously deliver stimulation to my pet?*

**ANS:** The maximum amount of time you can press the Stimulation Button and deliver stimulation to your pet continuously is 10 seconds. After this, the Remote Transmitter will time-out, and the Stimulation Button must be released and pressed again.

## ***My pet does not respond when I press a button***

- Make sure the Collar Receiver has been turned on.
- If your range has reduced from the first time you used the Dog Training Collar, the battery(s) may be low in either the Remote Transmitter or Collar Receiver.
- Many factors can impact the amount of range you have with the Remote Trainer. For a list of these factors, see "How the System Works".
- Test the Collar Receiver. See "How to test the functions" for details.
- Increase the Stimulation Level. Refer to "How to find the best Vibration/Shock Level for your pet" for more information.
- Make sure the Collar Receiver's Contact Points are placed snugly against your pet's skin. Refer to "How to Fit the Receiver Collar" for more information.

---

## ***The Collar Receiver will not turn on***

- Make sure the Collar Receiver has been charged. For the initial charge, be sure to charge it for 4 hours. Subsequent charges only take 2~3 hours.

---

## ***The Collar Receiver is not responding to the Remote Transmitter***

- Verify the Collar Receiver is on.
- If the indicator light is blinking rapidly, fully charged the Collar Receiver..
- If the first two solutions did not resolve your problem, see "How to syncing the Remote Transmitter & Collar Receiver"

## **USA**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a specific installation. If interference does occur to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult customer care, the dealer, or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.