

**WIC501 Wireless Charger
Product Instruction Manual**

01 / Product Parameters

Model: WIC501

Input: 5V*2A/9V*2A/12V*2A

Output: 5V*1A / 9V*1.67A /12V*1.2A

Frequency: 110KHz~205KHz

Ambient temperature: -5°C—40°C

02 / Operation Method

1. Install the Wupi wireless chargers WIC501 on the Wupi motorcycles bracket, and insert the USB terminal into the USB charger interface of the Wupi motorcycles.
2. In order to start wireless charging for the phone, please make sure the wireless receiving position of phone is placed correctly on the transmitting range of the wireless charger, then press the USB switch of the Wupi wireless chargers to start charging(Usually the wireless receiving position is at the center of the phone);
3. When the charging is completed or the charging needs to be stopped, press the USB switch of the Wupi wireless charger again, and the indicator light will go out.

Note: This wireless charger is not limited to use on motorcycles only.

03/ Indicator LED

Stand-by	Blue light always on
Working--Fast charging	Red light always on
Working--Slow charging	Blue light flashes
Metal foreign objects detected or Insufficient input powerout or deviation from the right position	Red light flashes

04/ Notes:

1. Please make sure the phone is placed on the center of the wireless charger. Deviation from the center will decrease the charging efficiency or interrupt the charging.
2. It should be less than 4mm for the thickness of the phone case, and there should be no foreign metal objects in the charging area between the phone and wireless

charger. Otherwise, the charging efficiency will be decreased, or the charging could be interrupted, even it could lead to latent danger.

3. It is highly recommended that the ambient temperature should be below 28 degrees Celsius (82.4 degrees Fahrenheit) during the charging period. it could decrease charging efficiency or lead to interruption for the higher ambient temperature.

05/ Safety tips

1. Do not put foreign metal objects in the charging area between the phone and wireless charger, which will lead to latent danger.
2. Do not put magnetic stripe cards (such as credit cards, telephone cards, bank cards, etc.) or some medical equipment (such as pacemakers or hearing aids) together with this product, which may cause damage to the magnetic stripe or abnormal operation of the equipment.
3. Do not apply heavy pressure and place it out of reach of children or animals.
4. Do not disassemble, refit and repair the wireless charger by oneself, otherwise it will not be able to carry out normal after-sale service.

06/ Warranty

The warranty of this product is twelve months. Failure or damage not caused by human factors, please contact the purchasing channel or Brand side for after-sales service under warranty.

The warranty does not apply to the following:

1. Damage caused by force majeure.
2. Failure or damage of the product caused by human factors.
3. Warranty expired.

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Radiation Exposure Statement

This device complies with RF radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

This device must operate with a minimum distance of 20 cm between the radiator and user body.