



audioboo

User Manual

Pairing:


- The AudioBox can pair with maximum 1 headphone and memorize maximum 2 headphones.
- The data of first paired headphone will be overwritten if a third headphone is paired, and so on.

1



Set the headphone to pairing mode.


2



Slide the Bluetooth switch to "PAIR" and **hold for 3 seconds**.


The light will start flashing and stop once paired with your headphone.

Reconnection:



The AudioBox will automatically connect to a previously paired headphone when the Bluetooth switch is on.


Waking Up:



It is not necessary to frequently switch the AudioBox on and off. For power saving purposes, the AudioBox will switch to **sleep mode** after **one minute** if no headphone is connected. **Slide** the Bluetooth switch to "PAIR" to **wake it up**.


Voice Chat:

- The microphone can be used without Bluetooth.
- The volume and sound quality can be adjusted in XBOX's system. Press the "XBOX" button on the controller to call up the menu, then select the speaker icon at the bottom.



Switch on the built-in microphone and the microphone indicator will light up.

Reset:



Slide the Bluetooth switch to "PAIR" and **hold for 8 seconds until the light stops flashing**.

FCC Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.