

无线鼠标说明书

1. 包装内容
 无线鼠标、usb 无线接收器、AA 电池、使用说明书
2. 技术参数
 无线频率 2.4G, 接口类型 usb, 电池要求 AA 碱性
3. 系统要求
 window 系统 MAC 系统
4. 安装说明
 鼠标底部电池槽, 取出接收器插入电脑 usb 接口, 等待 15 秒, 电池装入鼠标, 打开开关即可使用。

Wireless Mouse Cookbook

1. Packaging content wireless mouse, usb wireless receiver, AA battery, instruction manual
2. Technical parameters Wireless frequency 2.4G, interface type usb, battery requirements AA alkaline
3. The system requires the window system MAC system
4. Installation Instructions The bottom battery compartment of the mouse, remove the receiver plug into the computer usb interface, wait 15 seconds, the battery loaded into the mouse, turn on the switch to use.

FCC Requirement

changes or modifications not expressly approved by the party responsible for compliance could void the user' s authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.