

128双铜 单黑 折页 展开尺寸300*100 成品尺寸60*100mm

BOOMS BASS

使用说明书

M3201 +

MM

WLM

TWS

PORT

详细参数

方案:

蓝讯

版本:

5.2

功能:

TF, FM, USB, BT, AUX TWS, MIC

电池:

18650.3600MA

颜色:

黑,棕,绿,粉

喇叭直径:

78mm*2

喇叭功率:

4Ω 10W*2

电压:

Type-C DC 5V

充电时间:

about 5h

工作作时间:

3-6h

单机净重:

2080g

产品尺寸:

271*151*168mm

面板按键说明

按键功能

- "VOLUME" 顺时针为开机/加大音量, 逆时针为关机/减小音量。
- "ECHO" 话筒音量调节键, 顺时针为加大音量, 逆时针为减小音量。
- 在音乐模式下 短按 "◀" 上一曲, 在音乐模式下 短按 "▶" 下一曲。
- 短按 "M" 暂停/播放, 当两个设备同时连接的情况下, 双击为切换 (TWS), 当前所听设备, 连接成功。
- 长按 "M" 播放音源切换模式 (TF, FM, USB, BT, AUX)。
- 触控 "☀" 灯光变化, 长按开启/关闭灯光。
- 触控 "⌂" AUX音源输入
- 触控 "⌂" TF下 插入U盘自动解码切换播放模式播放音乐。
- 触控 "⌂" 插入U盘自动解码切换播放音乐。
- 触控 "⌂" 充电输入, 1W 5V插入充电。

话筒按键说明

使用说明

通过蓝牙连接手机使用

- 1.打开音箱电源: 长按开关键开机,电源指示灯会开始闪烁。
- 2.蓝牙连接: 打开手机蓝牙并扫描,搜索到"黑号"后,点击,进行配对连接。连接成功时音箱会发出提示音,电源指示灯变为常亮。
- 3.打开麦克风: 长按麦克风上的电源键并打开麦克风,开机后会自动检测并播放,若网上对应的指示灯会亮起。
- 4.调整音效: 调节好声音前定麦克风的音,并选择合适的音效。

播放音乐: 打开手机的音乐APP,选择喜欢的歌曲或伴奏开始播放。音乐的声音也可通过手机调节。

如何充电

- 1.当电池电量过低,产品会自动关机。
- 2.使用DC5V充电器连接并给麦克风的充电口进行充电。充电时充电指示灯会亮红色,充满后指示灯会熄灭。
- 3.麦克风充满电约2小时。充电后可连续使用约1小时。

请使用匹配的充电线及电压,否则会有危险及设备损坏。

BOOMS BASS

User Manual

M3201 +

MM

WLM

TWS

PORT

detailed parameters

Chip:

Lanxun

Version:

5.2

Function:

TF, FM, USB, BT, AUX TWS, MIC

Battery:

18650.3600MA

Color:

Black, Brown, Orange

Horn size:

78mm*2

Horn Impedance:

4Ω 10W*2

Voltage for Charging:

Type-C DC 5V

Charging time:

about 5h

Working time:

3-6h

Product N.W:

2080g

Product size:

271*151*168mm

Panel Key Description

Key functions

- "VOLUME" 顺时针为开机/加大音量, 逆时针为关机/减小音量。
- "ECHO" 话筒音量调节键, 顺时针为加大音量, 逆时针为减小音量。
- 在音乐模式下 短按 "◀" 上一曲, 在音乐模式下 短按 "▶" 下一曲。
- 短按 "M" 暂停/播放, 当两个设备同时连接的情况下, 双击为切换 (TWS), 当前所听设备, 连接成功。
- 长按 "M" 播放音源切换模式 (TF, FM, USB, BT, AUX)。
- 触控 "☀" 灯光变化, 长按开启/关闭灯光。
- 触控 "⌂" AUX音源输入
- 触控 "⌂" TF下 插入U盘自动解码切换播放模式播放音乐。
- 触控 "⌂" 插入U盘自动解码切换播放音乐。
- 触控 "⌂" 充电输入, 1W 5V插入充电。

Microphone Button Description

instructions

ing to your phone through Bluetooth connection

1. Turn on the speaker power. Press and hold the power button to turn on the speaker, and the power indicator light will start flashing.
2. Bluetooth connection: Open the phone's Bluetooth and scan. After searching for "Model", click Make pairing connection. When the connection is successful, the speaker will emit a beep and the power indicator light will change. It is always on.
3. Turn on the microphone: Press and hold the power button on the microphone to turn on the microphone and turn it on the rear of the machine will automatically connect to the speaker, and the corresponding indicator light on the speaker will light up.
4. Adjust the sound effect: Adjust the volume of the speaker and microphone, and select the appropriate sound.

Play music: Open the music app on your phone, select your favorite song or accompaniment to start play. The volume of music can also be adjusted through your phone.

How to charge

1. When the battery level is too low, the product will automatically shut down.
2. Use a DC5V charger to connect to the charging port of the speaker or microphone for charging. The charging indicator light will turn red when charging, and will turn off when fully charged.
3. Fully charge the microphone for about 2 hours. After charging, it can be used continuously for about 1 hour.

Please use a matching charging line and voltage, otherwise there may be danger And equipment damage.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.