

English (English)

## Read the manual before use

Important: Plug in the charging wire for charging at the first time after receiving the goods, and use it after fully charging, which can make the Wireless earphone last longer.

Important: Do not use super fast charging with current above 2A to avoid damaging the circuit chip due to excessive current.



Indicator Lights:  
When the earbuds are charging, the red light turns on; after fully charged, the red light turns off.  
When the charging case is charging, the red light flashes; after fully charged, the red light stays on.



Turn on Wireless on your mobile phone, search for SP13 devices and click on the connection.



Model : SP13  
Press and hold for about 5 seconds to turn on/off.



The touch control position of the earphones is within the white circle.

If only one earphone has sound, please delete the connected "SP13" first, turn off the wireless function of the phone, the earphone needs to be paired once, enter the tws mode, and then return to the first step


## The connection steps are as follows:

When taking the TWS earbuds out of the charging case, they will automatically turn on and pair. (When the earbuds are turned on, the red/blue indicator lights on the earbuds will flash alternately. When the TWS pairing is successful, the red/blue indicator light on one earbud will flash alternately, and the indicator light on the other earbud will go out. After connecting to the phone, the indicator lights on both earbuds will go out completely.)

The power delivered by the charger must be between min 2.5 Watts required by the radio equipment, and max 10 Watts in order to achieve the maximum charging speed.

## Touch function:

1. Short - press to play/pause, answer calls, and hang up calls. When a call comes in, long - press to reject the call.
2. Double - tap the touch area of the left/right earbud to switch to the previous/next track.
3. Triple - tap the touch area of the left/right earbud to decrease/increase the volume.
4. Long - press for 1.5 seconds to activate the Siri function. Short - press to exit the Siri function.



## FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.