




Indicator light

Operate instruction

Attention



Register an account

Add the lock

If the QR code lost, it can add the lock by Bluetooth

> Attention

Register fingerprints

The figure consists of eight screenshots from an Android application, arranged in two rows of four. The top row shows the initial state: a home screen with a lock icon and 'Log in' button; a 'No data' screen for fingerprint management; a 'Change remark name' dialog box; and a 'Name' dialog box. The bottom row shows the process of adding a new fingerprint: a 'No data' screen for fingerprint management; a 'No data' screen for fingerprint management; a 'No data' screen for fingerprint management; and a 'No data' screen for fingerprint management. Red circles highlight the 'Log in' button on the home screen and the 'Add new fingerprint' button on the 'No data' screens.


TECHNOLOGY HAS CHANGED LIFE

Attention

Only administrators can set to register fingerprints and delete fingerprints. The old version locks can not delete single fingerprint.

Add friends



Friends needs to download "OKLOK+" APP firstly. Register an account and login - Click "Friends" at the bottom - Click "Add friend" at the top right - Input phone number or emails of administrator - Administrator receive friend's request (by SMS or email) - Administrator agree (become friends) - Refuse can not be friends.




TECHNOLOGY HAS CHANGED LIFE

Remotely authorize

Authorize by administrator: Only administrators can authorize users. Enter the APP - Click the lock name - Click "Auth" in the bottom - Choose "permanent auth / periodic auth / temporary auth" to friends.




TECHNOLOGY HAS CHANGED LIFE




Authorize to friends: Click "Friends" in the bottom- Choose & Click the friend - Click "Auth" button- Authorize friends' permanently or batch.

TECHNOLOGY HAS CHANGED LIFE




Request Authorization: applicant click [icon] or [icon] - Scan the QR code / Search Bluetooth-Apply to Auth- Prompt administrator (by SMS or email) - Administrator Click "Agree" (authorize successfully) - Click "refuse" means not to authorize). At the same time the two users become friends automatically.

TECHNOLOGY HAS CHANGED LIFE




Cancel opening authorization



TECHNOLOGY HAS CHANGED LIFE

View opening records

View the phone's opening record: Click "Records" in the bottom - View phone's all opening records, including the user and the open time.




View fingerprint opening record: Enter the lock name - Click "record" button - Click "Synchronize fingerprint opening record" - Touch fingerprint panel- Synchronize fingerprint unlock record after connected automatically.

TECHNOLOGY HAS CHANGED LIFE

Attention

During synchronizing fingerprint opening records, it should make the phone close to the lock. Please do not disconnect Bluetooth or shut off the APP midway, otherwise it will lead to the records incomplete. Usually it stores fingerprint opening records in the built-in memory inside the lock. Due to memory limits, up to 200 unlock records will be stored. Old records will be deleted automatically when memory is full.



TECHNOLOGY HAS CHANGED LIFE

Service support

In personal center, it can contact with our customer service officer online or by telephone, or write down your questions or suggestions through "Feedback". Our reply can be found in "Feedback record".

Charge problem

If it occurs the situation, ① the indicator light does not flash; ② the red light flashes and the lock cannot be opened; ③ the lock cannot be locked, it should be in low battery or out of power. Suggest to charge the lock for half an hour before opening. If it does not flash blue light when charging the lock, please check the charge port whether USB cable is plugged in upside down. Please plug in the USB cable properly. Cable plugged in reversely will fail to charge and may damage the battery. If the lock does not charge after USB cable is plugged in properly, please clean pins in charge port with a Q-tip and try again. If the lock still does not charge after all attempts, please contact customer service.



NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.