



Wireless bone conduction headphones



Instructions for usage and warranty

Operating instructions and Warranty description

Schematic diagram



Parts list

1: Headphone x1 2: Charging cable x1 3: Instruction manual x1

Instructions

Wireless connection

When using it for the first time, turn on the headset. It will automatically enter the Wireless pairing state. Then, search for devices in your phone's Wireless settings, and you'll find the headset named " X27 ". Tap to connect. Once connected successfully, the headset's indicator light will turn off.

Changing and Auto-reconnecting Headset Pairing Devices

To change the paired headset device, first disconnect the current one. The headset's indicator will then flash red and blue alternately. Other devices can search for the headset named " X27 " and connect to it by tapping.

The " X27 " headset features an auto-reconnect function. When powered on normally, it will automatically connect to the last paired device. Ensure that the Wireless of the front-end device (e.g., mobile phone) is enabled for a successful reconnection.

Charging

Normal connection, the phone will display the headset battery, such as the battery display red, that is, the meter show the need to charge, plug in the charging line to charge. about 2 hours to fill, charging status indicator is red light, full charge often blue light .

Note Please use a USB power adapter with an output of 5V less than 1A.



The rechargeable battery of this product must be properly disposed of for recycling. Please do not place the battery in a fire to avoid explosion.

Operating instruction

| Function | Operation | Status |
|--|--|---------------------------------|
| Power on | Press '  ' for 3-5s | The blue light stays on for 1s. |
| Power off | | The red light stays on for 1s. |
| Volume + | Click '  ' | Wireless connected |
| Volume - | Click '  ' | |
| Next song | Press '  ' for 1s | Music playing |
| Previous song | Press '  ' for 1s | |
| Pause | Click '  ' | Music pause |
| Resume | | |
| Hang up | | Phone calls in |
| Answer the call | Press '  ' for 2s | |
| Decline the call | On the phone | |
| Switch between Phone/Headset earpieces | 4-click '  ' | Wireless connected |
| Switch between Game/Music mode | | |

Indicator

| | |
|--------------------|---------------------------------------|
| Search for a match | Red and blue lights flash alternately |
| Charging | Normally on red light |
| Finished charging | Normally on blue light |

AI intelligent voice control

(Phone needs to support voice wake-up function)

| Function | Operation | Status |
|---------------|--|--------------------|
| Voice control | Double-click '  ' | Wireless connected |

When the headset is already connected, double-click the '' button. After hearing the prompt tone, you can activate the function of voice-controlling the mobile phone. This operation can not only significantly save the operation time but also make the process of using the mobile phone more convenient and intelligent.

For example: You can directly control the earphone and ask:
What time is it now.....Today's weather.....
Navigate to Taipei 101.....Call someone

Smart exercise, easy and full of fun

MP3 Mode Operation Guide

Wireless / MP3 Mode Switch

Triple - click “  ” to switch between Wireless and MP3 (TF card) modes. (Defaults to Wireless on boot.)

Song Download

Connect the original charging cable to computer & earphones.
Transfer songs from computer to the U - disk.

MP3 Playback Mode Switch

In MP3 mode, 4 - click “  ” to switch between shuffle/sequential play (with memory function).

Troubleshooting

Unable to boot

Check if fully charged, for misoperations. Recharge and activate.

Unable to connect to Wireless

See if indicator flashes red & blue (alternating). If blue “breathing”, disconnect from other devices first.

Can't pair back

Ensure Bluetooth (or front - end) is on.

Low headphone volume

Check phone volume settings. Confirm wearing is correct.

Product parameter

Model: X27

Version: 6.0

weight: ≈28g

Battery: 220mAh

Input: 5V/180mA

Charging time: ≈2h

Call parameters: -42dB

Distance: 10 meter

Operating time : ≈8h@60% Volume

Profile: HFP A2DP AVRCP

Music format support: MP3, WAV, WMA, FLAC, M4A

Care and cleaning

- The product cannot be soaked in water, otherwise it will short-circuit and burn out.
- If not used for a long time, please fully charge it at least once a month.
- Do not disassemble any part of the product without permission. If you find that the earphone is defective, please stop using it.
- Keep the product away from fire, heat, freezing, and chemicals. Do not immerse the earphone in water, and do not wipe it with chemicals such as aromatherapy water.
- Store in a cool, dry place. Do not expose the product to direct sunlight for a long time.
- Please use a USB power adapter with an output of 5V less than 1A.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



Product warranty card

This card is a product warranty certificate, please keep it properly

| | |
|----------------|----------------|
| Product name: | Product model: |
| Purchase date: | Clients name: |
| Contact: | |

Product maintenance records

| Date | Bad phenomenon | Solution |
|------|----------------|----------|
| | | |
| | | |
| | | |