




Setup and Installation Guide



Installation video tutorials and tips

Visit the online setup guide for extra help.

We have an online guide with videos and tutorials all about setting up and using your camera.

www.momentss.com

Step1:

Download the Momentss App

The application will guide you through the installation and use process, but if you like to read paper content, we also provide this manual.




Step2:

Turn on the camera

Notice - For the first use, please fully charge the camera before turning it on; or directly plug the power cord into the power jack for long-term use.


Charging - You need to charge it periodically by plugging the provided cable into the charging port. Then you can put it anywhere without charging cable.



Power Button - Turn the power button on the bottom of the product to "ON".

MicroSD card - Make sure the camera has been turned off, then install the MicroSD card into the card port on the side of the camera.

•MicroSD card is not included in the package, which needs to be purchased separately. The maximum capacity is 128GB. Meanwhile, 64GB and above only support exFAT format. We recommend that the speed of read and write should not below U1/Class 10.




Attention! Please turn off your camera before install or remove the SD card.

Step3:

Binding device

Open the App, after completing the registration, click the "+" in the upper right corner of the homepage, and add devices according to the app prompts.



FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body. Use only the supplied antenna.


www.momentss.com

Step4:

Set and pair the Wi-Fi

When connecting, you should ensure that it is 2.4Ghz Wi-Fi and the network is unblocked. If the camera is turned on normally, please follow the app prompt to connect the device.

Side Indicator light




Green flashing: Waiting for scanning...
Blue flashing: Connecting...

Shooting - Tap this button to record real-time video as needed. The duration of the video can be customized through the app.

Reset - Press the reset button for 10s to restore the factory settings. The contents of the SD card will not be deleted.

Shooting / Press the reset



Congratulations!

Then check out the following advanced features...



About Indicator light

Indicator light description (front)
When the camera is in the working state of shooting, it will light up green.

Front Light	Green light	light Off
Mode	shooting	Not shooting

Side indicator

Green flashing: Waiting for scanning...
Green slowly flashing: OTA upgrade...
Blue flashing: Connecting...
Red flashing: charging...

Multi-scene placement

Using the bracket, you can put the camera wherever you want, even taking to the park outside.

Attention! Extra brackets need to be purchased separately

Product basic parameters

Product	Momentss smart camera
Color	Black & Wirte
Input	DC 5V-1A
Resolution	1920*1080
Temperature	0-50 C
Wi-Fi	Wi-Fi 2.4GHz
System	Android & iOS
Size	61 X 61 X 20 (mm)
Weight	60g
Angle	120°
Video encoding format	HEVC
Storage	MicroSD card (max support 128GB)
Battery Capacity	650mAh

Q&A

Q: Can the camera be used without power cord?
A: Yes. When not connected to the power supply, the camera will automatically run in a low power consumption mode, that is to say, it will only take pictures when a constant temperature organism is detected.
Q: Can I use the camera without network?
A: It can be used without Wi-Fi. The camera will record the detected events normally, and save the video to the server or MicroSD card, which can be viewed after connecting to the Internet.
Q: Does the camera support 5GHz Wi-Fi?
A: Not supported. Only 2.4GHz is supported.
Q: Can I use the camera without Micro SD card?
A: Yes. Without the Micro SD card, the normal use of the

camera will not be affected. The video can still be recorded and stored in the cloud, the detection and push functions can also be used normally.
In order to view the history more conveniently, we recommend that you use the Micro SD card.
Q: What is the maximum capacity of the Micro SD card supported by the camera?
A: 128G
Q: Can I watch the real-time monitoring picture and conduct real-time intercom via mobile phone
A: Yes. This function will be implemented through subsequent upgrades.
Q: Can the camera take the picture without lights at night?
A: Yes, night vision mode will be automatically turned on at night.