

Musilab Audio OPERATING INSTRUCTIONS

— SOLO 4/ SOLO 4T —

What's in the box (See Fig 1):

1. 1 Pairx SOLO Speaker
2. 1 x Power Cable
3. 1 x AUX Audio Cable
4. 1 x Speaker cable
5. 1x Optical cable(SOLO 4T only)
6. 1x Remote control(SOLO 4T only)




Fig 1

Product over view

Front view

Back view





Fig 2

Back panel for SOLO 4T

Back panel for SOLO 4



Getting Started

1-Power it Up!

- Connect Power cable from speaker AC power input port to city power outlet.
- Turn on the Power switch
- The Led light on back panel flash, speaker plays prompt sound.

2-Turn it On!

- If speaker in standby mode, Press and hold “**Volume**” knob for 2seconds until speaker plays prompt sound, and Led light on.

4-Select input mode (Audiosourceselection)

- **FOR SOLO 4**
Short press “**Volume**” knob to select the input mode (select audio source): **Wireless BT** audio, **AUX in** source”. The LED light change color accordingly (Blue for **Wireless BT** / Green for **AUX in**)
- **FOR SOLO 4T**
Short press “**Volume**” knob to select the input mode (select audio source): **Wireless BT** audio, **AUX in** or **Optical in** source”. The LED light change color accordingly (Blue for **Wireless BT** / Green for **AUX in** / white for **Optical in**)

5-Pair it up!

- Short press the “**Volume**” knob to select **Wireless BT** mode, speaker plays prompt sound and Blue led flash.
- If speaker already paired to other device, double click “**Volume**” knob, disconnect the exiting connection and enter pairing mode.
- Consult your phone/tablet/laptop instructions for pairing to a wireless BT device and connect to the device named “**Musilab SOLO 4 / Musilab SOLO 4T**”.
- Speaker will announce prompt sound when paired properly.

6- Remote control! (for SOLO 4T only)




Fig 5

EXPERT LEVEL

1. **Volume control**- You can turn up or down the **Volume** knob to change music simply.
2. **Bass control**- You can turn up or down the **Bass** knob to adjust the Bass sound level.
3. **Treble control**- You can turn up or down the **Treble** knob to adjust the Treble sound level.
4. **Connect via AUX cable** - Connect the speaker to your PC, laptop, or other device with audio output, using the included audio cable plug into AUX port located on back panel, short press the **Volume** knob to enter **AUX in** mode, enjoy your music.
5. **Connect via Optical cable**(SOLO 4T only) – For digital input source, using the included Optical cable plug into Optical port located on back panel, short press the **Volume** knob to enter **Optical in** mode, enjoy your music.

6.EXTRA DETAILS

- **Automatic Power-Off** - If there is no sound coming through the speaker for approximately 30 minutes, the speaker will automatically go to standby mode to save power.
- **Shut OFF power**-We recommend to turn off the main power switch, If the speaker doesn't be used for long time.
- **Tech Specs**
 - o Power Output: 36 Watts Rms
 - o Drivers: 4 Inch 4Ω woofer, 1 Inch 6Ω tweeter
 - o BT5.0, A2DP Audio protocol
 - o Wireless BT Connection Distance: 30ft to phone
 - o Frequency response: 60Hz – 18KHz
 - o Power supply: AC 100-240V 50/60Hz

If All Else Fails, Get in Touch

support@musilab.com.cn | www.musilabaudio.com

FCC Information

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC ID:2AXXD-MLBT2101