

 @eppfunofficial

 @eppfunofficial

 @eppfun

 @eppfunofficial

 www.meppfun.com

 service@meppfun.com

www.meppfun.com
Shenzhen Changsheng Technology Co., Ltd.
4#405 Xinggang Tongchuanghui, No.6099, Bao'an
Avenue, Qiaotou Community, Fuhai Street, Bao'an
District, Shenzhen(CN) 518103
Product ID:L5008 Made in China
Service@meppfun.com

eppfun

eppfun

Cute meet 600


English
(1-14)

Deutsche
(15-22)

日本語
(23-30)



中文
(31-38)

Cute meet 600



- Model : Cute meet 600
- Product ID : LS006
- BT Version : V5.2
- Frequency Band : 20Hz~20KHz
- Output Power : 10mW(0db,1KHz)
- Working Temperature :0~45°C
- Total Playtime : about 32hours
- Charge Time : 1~2hours
- Input Standard : TYPE-C,USB 5V/1A
- Transmission Distance : 10meters
- Product Size :
Charge Case : 85.4*34.5*19.2mm
Earbuds : 32.6*17.3*16mm

Product Overview



What's in the Box

- Cute meet 600 Wireless Earbuds X 2
- Cute meet 600 Charging Case x 1
- Silicone Earhooks x 2
- Memory Foam Eartips x 2
- Silicone Eartips A x 6
- Silicone Eartips B x 6
- Protective Case x 1
- USB C Charging Cable x 1


How to Wear

1. Please choose the suitable size ear tips to fit your ears


2. Please adjust your earbuds directions to fit your ears

1. How to Pair

- (1) Take out the earbuds from the packaging and put them into the charging case
- (2) After 5 seconds, take out the earbuds from charging case. The earbuds will automatically enter bluetooth pairing (one white Led quickly flashes, the other one flashes per 5 seconds)





- (3) Select Cute meet 600 under bluetooth menu on your device. The bluetooth pairing is successful.



(4) Connect to one new device

When you want to connect to a new device, please turn off the Bluetooth connection between your earbuds and the current device. The one earbud white Led will quickly flash, then you select and connect to "Cute meet 600" on the Bluetooth connection interface of your new device.



2. Touch Control

Power on

-Take out earbuds from charging case

Power off

-Put earbuds into charging case.
-No connection within 3 minutes.


Manual Power On

-Long press the touch button 2 seconds.

	Tap :Play music / Pause	
 R	Double-tap: Play the next track	
 L	Double-tap: Play the previous track	
 L	Three-tap :On/off game mode	
 R	Three-tap :Activate voice assistant	
 R	Press 1 second: VOLup	
 L	Press 1 second: VOL down	
	Tap :Accept a call	
	Double-tap: Hung up a call	
	Press for 2 seconds :Reject a call	

3.Charging

Charge before the first use. Open the charging case and insert the left earbuds into the left charging compartment and the right earbud into the right charging compartment.



Charging Box

Low Power(<25%), Flash twice per second

Charging Flash Once per second

Full Power Light

4.Restore Factory Settings Guidelines

- (1)Please delete the Bluetooth pairing record on your device (Cute meet 600).
- (2)Put both earbuds into the charging case, the LEDs light for charging.
- (3)Long press for 5 seconds, the charging led is off.
- (4)Whin 5 seconds, take both them out from charging case
- (5)Enter into pairing between left earbud and right earbud, wait for several seconds, when one earbud quickly flash, the other one flash slowly.
- (6)The reset is successful, please choose the“Cute meet 600” on your device and click to connect.
- (7)The earbuds are connected to your device successfully, then enjoy yourself.

5.Tech Support & FAQ

(1).Left or right earbud cannot work.

Reason 1: Earbuds are out of power.

Proposal 1 : Put the earbuds in the charging case and close the cover of the charging case, then use the USB-C cord to charge the charging case.

Reason 2: Left and right earbuds are not paired with each other.

Proposal 2 : Refer to the above content 1 “Restore Factory Settings Guidelines” ,go through the reset operation to restore the connection.

(2).Earbuds won't disconnect while in charging case.

Reason 1: Due to the dirty, dust, grease, etc, the earbuds' pin needle and the charging case's pin needle cannot contact perfect.

Proposal 1: Use the soft cloth in the box to wipe the earbuds' and charging case's pin needle to solve your problem.

(3).Put earbuds in the charging case and close the lid of the charging case, the indicator light of the charging case does not light up.

Reason 1: Due to the dirty, dust, grease, etc, the earbuds' pin needle and the charging case's pin needle cannot contact perfect. The earbuds are not enter the charging state.

Proposal 1: Use the soft cloth in the box to wipe the earbuds' and charging case's pin needle to solve your problem.

(4).Earbuds don't work when the earphone is connected to the TV or the earbuds cannot connect to the TV automatically.

Reason 1: According to our analysis, the global TV brands, like Sony, Samsung, Huawei, Hisense, TCL and other brands have different priority settings for Bluetooth earbuds. This is decided by different UI design.

Proposal 1: On the TV terminal, set up the playback priority of earbuds and TV speakers.

Proposal 1: In the latest version, we equipped silica gel to match different ear types, it can provide better sealing between earbuds and ears.

Model Name :Cute meet 600

FCC ID : 2AY3ILS006. Made in China



This product contains a built-in rechargeable lithium battery.
Battery safety

warning :

Prohibit dismantling, impact, extrusion or into fire ; If there is serious swelling, do not continue to use ; Do not place in high temperature environment; Battery is banned after immersion.



EPPFUN One(1)Year Limited Warranty

EPPFUN,belonged to Shenzhen CHANGSHENG Technologies Co.,Ltd., extends You this Limited Warranty.Statutory or common law may provide You with additional rights or remedies,which shall not be affected by this Limited Warranty.Consumers have the right to choose whether to claim service under the EPPFUN One-Year Limited Warranty or under their consumer law rights.

Important:

The EPPFUN One-Year Limited Warranty terms and conditions shall not apply to consumer law claims.For further information about consumer laws,please contact your local consumer organization.

Product supp ort:

Access www.meppfun.com to get EPPFUN support and new info. If you have any question,can send email to service@meppfun.com get relevant support.

Remedies:

Your EPPFUN branded hardware product(“Product”)is warranted against defects in materials and workmanship for a period of One(1) Year from the date of original retail purchase(“Warranty Period”) when used in accordance with EPPFUN’s instructions in the provided user manuals.Under this warranty,you will be able to direct your claims to EPPFUN even in situations when you purchased the Product from third party.If a defect arises during the Warranty Period,

EPPFUN at its option will (1) repair the Product at no charge with new parts or parts that are equivalent to new in terms of performance and reliability; (2) exchange the Product with a product of equivalent functionality built with new and/or previously used parts that are equivalent to new in terms of performance and reliability or, with your consent, a product that is at least functionally equivalent to the product it

replaces; or (3) refund the original purchase price. This warranty excludes normal depletion of consumable parts, such as batteries, unless failure has occurred due to a defect in materials or workmanship and damage resulting from abuse, accident, modifications, unauthorized repairs or other causes that are not defects in materials and workmanship.

How to Get Warranty Service:

A Warranty Service Order must be requested from EPPFUN within the stated Warranty Period determined from the date of receipt of shipment. To request a Warranty Service Order, contact EPPFUN support team: service@meppfun.com. To obtain warranty service, in accordance with applicable law, EPPFUN may require the customer to provide proof of purchase details and/or comply with registration requirements before applying for Warranty Service. When contacting EPPFUN via telephone, call charges may apply depending on your location. Please contact your network operator for details.

Warranty options:

EPPFUN will provide warranty service through one or more of the following options:

(1) Carry-in service. You may return your Product to a EPPFUN Retail or EPPFUN Authorized Service Provider location that offers carry-in service.

(3) Do-it-yourself (DIY) parts service. DIY parts service allows you to service your own Product. If DIY parts service is available at the circumstances, the following process will apply:

(i) When EPPFUN requires return of the replaced Product or parts, EPPFUN may require a credit card authorization as security for the retail price of the replacement Product or parts and applicable shipping costs. If you are unable to provide credit card authorization, DIY parts service may not be available to you, and EPPFUN will offer alternative service. EPPFUN will ship a replacement Product or parts to you with installation instructions, and, if applicable, any clear requirements for the return of the replaced Product or parts. If you

follow the instructions, EPPFUN will cancel the credit card authorization, so you will not be charged for the Product or parts. If you fail to return the replaced Product or parts as instructed or return a replaced Product or parts that are not eligible for service, EPPFUN will charge your credit card for the authorized amount.

(ii) When EPPFUN does not require return of the replaced Product or parts, EPPFUN will ship free-of-charge replacement Product or parts accompanied with instructions and, if applicable, any clear requirements for the disposal of the replaced Product or parts.

(iii) EPPFUN is not responsible for any labor costs you incur relating to DIY parts service. EPPFUN reserves the rights to modify the warranty service. Should you require further assistance, contact EPPFUN via service@meppfun.com.

To Apply for a Refund, the Following Conditions Must be Met

There are a few important things to keep in mind when returning a product you purchased from EPPFUN: (1) A Return Merchandise Authorization (RMA) must be requested from EPPLA within 10 calendar days from the date of receipt of shipment. To request a RMA, contact EPPFUN support team via service@meppfun.com. If the applicable law at your country provides a longer period of revocation, the law shall prevail; (2) Only items that have been purchased directly from the EPPFUN online Store can be returned to EPPFUN. Products purchased through other retailers must be returned in accordance with their respective refund and return policy; (3) Returned product and packaging must be in good physical condition (i.e., not physically broken or damaged); (4) Please ensure that the item you're returning is repackaged with all the cords, adapters and documentation that were included when it was shipped; (5) The shipping cost must be paid by the customer; (6) Necessary contact information (including but not limited to name, phone number, address, email, purchase date, etc.) must be clearly displayed on the printing template provided by the EPPFUN support team, and must be included along with the returned product; (7) For warranty service, please keep your receipt and/or invoice as proof of purchase.

Limited Product Warranty

(1)EPPFUN is not responsible for damage arising from failure to following instructions to use the product.(2)For Latin American Consumers,customer service from EPPFUN service center or EPPFUN Retail is not available.To request a Warranty Service Order,contact local EPPFUN authorized dealers.(3)This warranty excludes normal depletion of consumable parts,such as batteries,unless failure has occurred due to a defect in materials or workmanship.(4)Any limitations of liability in this warranty document shall not apply to (i)death or personal injury pursuant to any mandatory law on product liability;(ii)fraud or fraudulent misrepresentation;(iii)intentional misconduct or gross negligence;(iv)a culpable breach of major contractual obligations.A damage claim based on a breach of major contractual obligations or gross negligence will be limited to foreseeable damage typical for the sales contract concerned.

Additional Terms and Conditions:

(1)Shipping and handling charges,gift wrapping fees and taxes paid (e.g.,state,customs,VAT)are not refundable.If your order contains multiple products and you only return a portion of them,please note that total shipping charges are not refundable.Partial shipping charges are also not refundable.(2)If you return a product to EPPFUN (i)without a RMA from EPPFUN;(ii)without all parts included in the original package,EPPFUN retains the right to refuse delivery of such return.If any term is held to be illegal or unenforceable,it shall be severed from this warranty and the legality or enforceability of the remaining terms shall not be affected. This warranty is governed by and construed under the laws of the country in which the product purchase took place.

Important Safety Information:

Handle the EPPFUN headphones with care.They contain sensitive electronic components and batteries,which can be damaged or cause injury if dropped,burned,punctured,crushed,disassembled,or exposed to excessive heat or liquid.Don't use damaged EPPFUN headphones.Please follow the instructions:



CAUTION: Prevention of Hearing Loss
Permanent hearing loss may occur if headphones are used at high volume for prolonged periods of time.

To avoid damage to hearing,make sure that the volume is turned down before playing music on your headphones.If your ears start ringing or aching,remove the headphones immediately and have your hearing checked.To protect your hearing:

- Always listen at a low to moderate volume.
- Remember to rest your ears once in a while.
- Limit the amount of time you use the headphones at high volume.
- Avoid turning up the volume to block out noisy surroundings.
- Reduce the volume if you can't hear people speaking near you.

Traffic

The EPPFUN headphones effectively isolate external noise.Avoid using the EPPFUN headphones while driving a vehicle,crossing streets, or any activity that requires your full attention and capability to hear. Listening to music in traffic environments may lead to accidents.

Cleaning

Headphones can lead to ear infections if not properly cleaned.Use a soft lint-free cloth to clean headphones from time to time.Don't get moisture in any openings,or use aerosol sprays,solvents,or abrasives. If a skin problem develops,discontinue use.If the problem persists, consult a physician.

Batteries

Don't attempt to replace the batteries of EPPFUN headphones yourself. You may damage the batteries,which could cause overheating and injury.

- Do not use this product near water.
- Clean only with dry cloth.
- Only use accessories specified by the manufacturer.
- Refer servicing to qualified personnel.

Choking Hazard

The EPPFUN headphones may present a choking hazard or cause other injury to children.Keep them away from children.

Magnetic Fields

The EPPFUN headphones contain components and radios that emit electromagnetic fields.These electromagnetic fields and magnets may interfere with pacemakers,defibrillators,or other medical devices. Maintain a safe distance of separation between your medical device and the EPPFUN headphones.Consult your physician and medical device manufacturer for information specific to your medical device. Stop using the EPPFUN headphones if you suspect they are interfering with your pacemaker, defibrillator,or any other medical device.

Electrostatic Shock

When using the EPPFUN headphones in areas where the air is very dry, it is easy to build up static electricity, which causes possibility for your ears to receive a small electrostatic discharge from the EPPFUN headphones. To minimize the risk of electrostatic discharge, avoid using the headphones in extremely dry environments, or touch a grounded unpainted metal object before wearing the headphones.

Regulatory Compliance Information

FCC Compliance Statement:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1. This device may not cause harmful interference; 2. This device must accept any interference received, including interference that may cause undesired operation.

Important:

Changes or modifications not expressly approved by Shenzhen Technologies Co., Ltd. responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Caution!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Eu Compliance Statement

Eppfun declares that this wireless device is in compliance with the essential requirements and other relevant provisions of R&TTE Directive. This device can be used in the European Community.

The aim of EU's Waste Electrical and Electronic Equipment (WEEE) directives 2002/96/EC and the RoHS directive is to reduce waste from electric and electronic products and to recycle as much of the materials as possible. Any remaining waste should be virtually risk-free to handle and the risk of hazardous emissions should be minimal.


This product contains a built-in rechargeable lithium battery. Battery safety

warning:

prohibit dismantling, impact, extrusion or into the fire; If there is serious swelling, do not continue to use; Do not place in high temperature environment; Battery is banned after immersion.





Cute meet 600



- Modell: Cute meet 600
- Produkt-ID: LS006
- BT-Version: V5.2
- Frequenzband: 20Hz ~ 20KHz
- Ausgangsleistung: 10 mW (0 dB, 1 kHz)
- Arbeitstemperatur: 0~45°CGesamtspielzeit:
- ca. 32 Stunden
- Ladezeit: 1 ~ 2 Stunden
- Eingangsstandard: TYPE-C, USB 5V/1A
- Übertragungsentfernung: 10 Meter
- Produktgröße:
Ladehülle: 85.4 * 34.5 * 19.2 mm
Ohrhörer: 32.6 * 17.3 * 16mm

Produktübersicht



Was ist in der Box

- Netter Meet 600 Wireless Earbuds X2
- Cute meet 600 Ladekoffer x1
- Silikon-Ohrhaken x2
- Memory Foam-Ohrstöpsel x2
- Silikon-Ohrstöpsel A x6
- Silikon-Ohrstöpsel B x6
- Schutzhülle x1
- USB-C-Ladekabel x1

Wie zu tragen


1. Bitte wählen Sie die passenden Ohrstöpsel für Ihre Ohre

2. Bitte passen Sie die Richtung Ihrer Ohrhörer an Ihre Ohren an


1. So koppeln Sie

(1) Nehmen Sie die Ohrhörer aus der Verpackung und legen Sie sie in die Ladebox

(2) Nehmen Sie die Ohrhörer nach 5 Sekunden aus dem Ladeetui. Die Ohrhörer wechseln automatisch in die Bluetooth-Kopplung (eine weiße LED blinkt schnell, die andere blinkt alle 5 Sekunden).




(3) Wählen Sie Cute meet 600 im Bluetooth-Menü auf Ihrem Gerät. Die Bluetooth-Kopplung ist erfolgreich.



(4) Mit einem neuen Gerät verbinden

Wenn Sie sich mit einem neuen Gerät verbinden möchten, schalten Sie bitte die Bluetooth-Verbindung zwischen Ihren Ohrhörern und dem aktuellen Gerät aus. Die weiße LED des einen Ohrhörers blinkt schnell, dann wählen Sie „Cute meet 600“ auf der Bluetooth-Verbindungsschnittstelle Ihres neuen Geräts aus und stellen eine Verbindung her.



2. Touch-Steuerung

Ein

- Nehmen Sie die Ohrhörer aus dem Ladeetui heraus
- Manuelles Einschalten
- Drücken Sie die Touch-Taste 2 Sekunden lang.

Ausschalten

- Legen Sie die Ohrhörer in das Ladeetui.
- Keine Verbindung innerhalb von 3 Minuten.

	Tippen Sie auf: Musik abspielen / Pause	 
 R	Doppeltippen: Nächsten Titel abspielen	
 L	Doppeltippen: Vorherigen Titel abspielen	
 L	Dreimaliges Antippen: Spielmodus ein/aus	
 R	Dreimal tippen: Sprachassistent	 
 R	Drücken Sie: VOL auf	 +
 L	Drücken: VOL Down	 -
	Tippen Sie auf: Anruf annehmen	
	Doppeltippen: Anruf beenden	
	2 Sekunden lang drücken: Anruf ablehnen	

3

3. Aufladen

Vor dem ersten Gebrauch aufladen. Öffnen Sie das Ladeetui und stecken Sie die linken Ohrhörer in das linke Ladefach und den rechten Ohrhörer in das rechte Ladefach.



Ladebox

Geringer Stromverbrauch (<25%), Blitz zweimal pro Sekunde

Ladeblitz Einmal pro Sekunde

Volle Power Licht

4. Richtlinien zur Wiederherstellung der Werkseinstellungen

- (1) Bitte löschen Sie den Bluetooth-Pairing-Datensatz auf Ihrem Gerät (Cute meet 600)
- (2) Legen Sie beide Ohrhörer in die Ladebox, die LEDs leuchten zum Aufladen.
- (3) Langes Drücken für 5 Sekunden, die Lade-LED ist aus.
- (4) Nehmen Sie nach 5 Sekunden beide aus der Ladebox
- (5) Geben Sie die Kopplung zwischen dem linken Ohrhörer und dem rechten Ohrhörer ein, warten Sie einige Sekunden, wenn ein Ohrhörer schnell blinkt, blinkt der andere langsam.
- (6) Das Zurücksetzen war erfolgreich, bitte wählen Sie „Cute meet 600“ auf Ihrem Gerät und klicken Sie, um eine Verbindung herzustellen.
- (7) Die Ohrhörer sind erfolgreich mit Ihrem Gerät verbunden, dann genießen Sie es

(1).Der linke oder rechte Ohrhörer funktioniert nicht.

Grund 1: Ohrhörer haben keinen Strom.

Vorschlag 1: Legen Sie die Ohrhörer in das Ladeetui und schließen Sie die Abdeckung des Ladeetuis, dann verwenden Sie das USB-C-Kabel, um das Ladeetui aufzuladen.

Grund 2: Linker und rechter Ohrhörer sind nicht miteinander gekoppelt.

Vorschlag 2: Beziehen Sie sich auf den obigen Inhalt 1 „Richtlinien zum Wiederherstellen der Werkseinstellungen“, führen Sie den Reset-Vorgang durch, um die Verbindung wiederherzustellen.

(2).Ohrhörer werden im Ladekoffer nicht getrennt.

Grund 1: Aufgrund von Schmutz, Staub, Fett usw. können sich die Nadelnadel der Ohrhörer und die Nadelnadel des Ladekoffers nicht perfekt berühren.

Vorschlag 1: Verwenden Sie das weiche Tuch in der Verpackung, um die Nadel der Ohrhörer und des Ladeetuis abzuwischen, um Ihr Problem zu lösen.

(3).Legen Sie die Ohrhörer in das Ladeetui und schließen Sie den Deckel des Ladeetuis, die Kontrollleuchte des Ladeetuis leuchtet nicht.

Grund 1: Aufgrund von Schmutz, Staub, Fett usw. können sich die Nadelnadel der Ohrhörer und die Nadelnadel des Ladekoffers nicht perfekt berühren. Die Ohrhörer befinden sich nicht im Ladezustand.

Vorschlag 1: Verwenden Sie das weiche Tuch in der Verpackung, um die Nadel der Ohrhörer und des Ladeetuis abzuwischen, um Ihr Problem zu lösen.

(4).Prioritätseinstellungen für Bluetooth-Ohrhörer. Dies wird durch unterschiedliche UI-Designs entschieden.

Vorschlag 1: Richten Sie am TV-Terminal die Wiedergabepriorität von Ohrhörern und TV-Lautsprechern ein.

(5).Den Ohrhörern fehlt der Bass.

Grund 1: Die Semi-In-Ear-Ohrhörer haben das Merkmal eines unzureichenden Basses.

Vorschlag 1: In der neuesten Version haben wir Kieselgel passend für verschiedene Ohrtypen ausgestattet, es kann eine bessere Abdichtung zwischen Ohrhörern und Ohren bieten.



[R] 018-210175
株式会社神川




CCAP21LP1890E1

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:


- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Cute meet 600



- ・モデル :Cute meet 600
- ・製品ID :LS006
- ・Bluetoothバージョン :V5.2
- ・周波数帯 :20HZ-20KHZ
- ・出力電力 :10mw(0db、1KHZ)
- ・作動温度 :0-45 °C
- ・総再生時間 :約32時間
- ・充電時間 :1～2時間
- ・入力規格 :TYPE-C、USB 5V/1A
- ・伝送距離 :10メートル
- ・商品のサイズ : チャージケース 85
* 34.6 * 19mm イヤフォン :32.5 *
17.3 * 15.5mm

製品仕様



ボックスには

- ・かわいいミート600ワイヤレスイヤフォン
X2
- ・かわいいミート600充電ケースx1
- ・シリコンイヤークフ x2
- ・メモリーフォームイヤークリップx2
- ・シリコンイヤークリップAx6
- ・シリコンイヤークリップBx6
- ・保護ケースx1
- ・USBC充電ケーブルx1

着用方法

1. 耳に合う適切なサイズのイヤーチップを選択してください


2. 耳に合うようにイヤフォンの方向を調整してください

1. ペアリングについて


(1) イヤフォンをパッケージから取り出し、充電ケースに入れます (2) 5秒後、充電ケースからイヤフォンを取り出します。イヤフォンは自動的に Bluetooth ペアリングに入ります (1つの白いLEDがすばやく点滅し、もう1つは5秒ごとに点滅します)



(3) デバイスのBluetoothメニューで[かわいい会議600]を選択します。
Bluetoothのペアリングは成功しています。



(4) 1つの新しいデバイスに接続します 新しいデバイスに接続する場合は、イヤフォンと現在のデバイス間の Bluetooth接続をオフにしてください。1つのイヤフォンの白いLEDがすばやく点滅します。次に、新しいデバイスのBluetooth接続インターフェイスで「Cutemeet600」を選択して接続します



2. タッチ操作について

電源オン

- 充電ケースからイヤホンを取り出します。
- タッチボタンを2秒くらい長押しします。


電源オフ

- イヤホンを充電ケースに入れます
- 3分以内に接続がありません。

	ワンクリック :再生/一時停止	
 R	ダブルクリック :次の曲	
 L	ダブルクリック :前の曲	
 L	スリータップ :オン/オフゲームモード	
 R	雑音声アシスタン	
 R	1秒押す :音量を上げる	
 L	1秒押す :VOLダウン	
	ワンクリック :電話に出る	
	ダブルタップ :電話を切る	
	約2秒間長押し :通話を拒否する	

3

3.充電について 初めて使用する前に充電してください。充電ケースを開き、イヤホンの絶縁ステッカーをはがし、イヤホンを充電ケースに戻します。



充電ボックス低電力 (<25%)、1
秒に2回フラッシュ 1秒に1回フラッシュ
ユを充電する フルパワーライト

4.工場出荷時の設定ガイドラインを復元 (1)デバイスのBluetoothペアリングレコードを削除してください (Cute Meet 600)
(2)両方のイヤホンを充電ケースに入れると、LEDが点灯して充電します。
(3)5秒間長押しすると、充電LEDがオフになります。(4)5秒以内に両方を充電ケースから取り出します (5)左イヤフォンと右イヤフォンのペアリングを開始し、数秒間待ちます。一方のイヤフォンがすばやく点滅し、もう一方のイヤフォンがゆっくり点滅します。
(6)リセットに成功しました。お使いのデバイスで「Outemeet 600」を選択し、クリックして接続してください。(7)イヤフォンがデバイスに正常に接続されているので、楽しんでください。

工場出荷時の設定ガイドラインを復元

- (1)デバイスのBluetoothペアリングレコードを削除してください
(Cute Meet 600) (2)両方のイヤフォンを充電ケースに入れると、LEDが点灯して充電します。(3)5秒間長押しすると、充電LEDがオフになります。
(4)5秒以内に両方を充電ケースから取り出します(5)左イヤフォンと右イヤフォンのペアリングを開始し、数秒間待ちます。一方のイヤフォンがすばやく点滅し、もう一方のイヤフォンがゆっくり点滅します。
(6)リセットに成功しました。お使いのデバイスで「CuteMeet 600」を選択し、クリックして接続してください。(7)イヤフォンがデバイスに正常に接続されているので、楽しんでください。

5.よくある質問 (1)左耳または右耳に音が出ない 理由1 :イヤホンの電源が切れています。

解決策1 :イヤホンを充電ボックスに入れ、充電ボックスを閉じ、充電ボックスをUSB-Cに接続して充電します。理由2、左右のイヤホンがペアリングされていない。解決策2 :上記のコンテンツ1「イヤホンリセットガイドライン」を参照し、リセット操作を実行して接続を復元します。

(2)イヤホンを充電ボックスに入れ、充電ボックスの蓋を閉じても、イヤホンは音楽を再生します。理由1.汚れ、ほこり、グリースなどの理由により、イヤホンの充電ピンと充電ボックスの充電ピンが完全に接触していません。解決策1.ボックスに装着されている柔らかい布を使用して、イヤホンと充電ボックスの充電ピンを拭き、この問題を解決します。

(3)イヤホンを充電ボックスに入れ、蓋を開めます。充電ボックスの充電インジケータ
ーが点灯しません。理由1.汚れ、ほこり、グリースなどの理由により、イヤホンの充電ピンと充電ボックスが完全に接触していません。イヤホンが充電状態になりません。解決策1.ボックスに装着されている柔らかい布を使用して、イヤホンと充電ボックスの充電ピンを拭き、この問題を解決します。
(4)イヤホンをテレビに接続しても音が出ない/イヤホンが自動的にテレビに接続できない。

(3)イヤホンを充電ボックスに入れ、蓋を開めます。充電ボックスの充電インジケータ
ーが点灯しません。理由1.汚れ、ほこり、グリースなどの理由により、イヤホンの充電ピンと充電ボックスが完全に接触していません。イヤホンが充電状態になりません。解決策1.ボックスに装着されている柔らかい布を使用して、イヤホンと充電ボックスの充電ピンを拭き、この問題を解決します。


(4)イヤホンをテレビに接続しても音が出ない/イヤホンが自動的にテレビに接続できない。

理由1.分析の結果、グローバルTVブランド、Sony、Samsung、Huawei、Hisense、TCL、およびその他のブランドでは、Bluetoothイヤホンの優先順位設定が異なります。これは、設計UIの決定が異なるためです。解決策1 :TV側で、ヘッドホンとTVスピーカーの再生優先度を設定します。




CCAP21LP1890E1

Cute meet 600



- 型號 :Cute meet 600
- 產品型號 :LS006
- Bluetooth版本 :V5.2
- 頻段 :20Hz~20KHz
- 輸出功率 :10mW(0db、1KHz)
- 工作溫度 :0~45 °C
- 總播放時間 :約32小時
- 充電時間 :1~2小時
- 輸入標準 :TYPE-C ,USB 5V/1A
- 傳輸距離 :10m
- 產品尺寸 :
- 充電艙 :85 * 34.6 * 19mm
- 耳機 :32.5 * 17.3 * 15.5mm

產品概述



包裝盒內含有：

- Cute meet 600 無線耳機x2
- Cute meet 600 充電盒x1
- 矽膠耳掛x2
- 記憶棉耳塞x2
- 矽膠耳塞Ax6
- 矽膠耳塞Bx6
- 保護皮套 x1
- USB 充電線 x1

如何佩戴

1. 請根據自己需求選擇合適尺寸和形狀的耳膠


2. 請適當旋轉調整耳機, 確保舒適性和密封性。

1. 如何配對


(1) 從包裝盒中取出耳機, 放入充電盒中。 (2) 充電5S後, 將耳機從充電盒中取出, 耳機進入藍牙配對狀態 (一個耳 機燈快速閃爍, 另外一個耳 機慢閃, 5S閃一次)



(3) 在設備上的藍牙菜單下選擇“ Cute meet 600”, 藍牙配對成功。



(4) 當您要連接到新設備時, 請關閉耳機與當前設備之間的藍牙連接。當指示燈閃爍為白色時, 說明它們已進入配對模式。然後你可以選擇並連接到新設備藍牙連接界面上的 “Cute meet 600”。



2. 觸摸控制

開機

-將充電盒中取出耳機

手動開機

-長時間按下觸摸按鈕2-3秒鐘。

關機


-將耳機放入充電艙中。

-在3分鐘內沒有連接。

	點擊 播放音樂/暫停	
 R	雙擊 播放下一首	
 L	雙擊 播放上一首	
 L	三擊 打開/關閉遊戲模式	
 R	三擊 喚醒語音助手	
 R	長按 音量增大	
 L	長按 音量減小	
	點擊 接通電話	
	點擊 掛掉電話	
	長按兩秒 拒接電話	

3

3. 充電 在第一次使用前請先充電。打開充電艙，將左耳機插入左側充電艙，並將右耳機插入右側充電艙。



充電盒

低電壓 (<25%) 白燈每秒閃2次

充電狀態 白燈每秒閃1次

充滿電 白燈長亮

4. 耳機複位指引

- (1) 請刪除您設備上的藍牙配對記錄 (Cute meet 600)
- (2) 將兩個耳塞放入充電盒，充電時LED燈亮。
- (3) 長按5秒，充電指示燈熄滅。
- (4) 等待5秒，將它們從充電盒中取出
- (5) 進入左耳機和右耳機配對，等待幾秒鐘，一個耳機快閃，另一個慢閃。
- (6) 重置成功，請在您的設備上選擇「Cute meet 600」並點擊連接。
- (7) 耳塞已成功連接到您的設備，然後盡情享受吧。

5.技術支持和常見問題解答

(1).左耳或者右耳沒有聲音

原因1 :耳機沒有電了

方案1 :耳機放入充電盒 ,關閉充電盒子 ,同時也將充電盒插上USB-C 充電。

原因2, 左右耳機沒有配對 方案2 :參考以上內容1《耳機複位指引》,進行複位操作即可回復連接 :

(2).耳機放入充電盒 ,蓋上充電盒蓋子 ,耳機仍然播放音樂 原因

1. 由于髒汙 ,灰塵 ,油脂等原因導致 ,耳機充電pin針和充電盒充電 pin 針不能

完整接觸。

方案1. 使用包裝盒內佩戴的軟布擦拭耳機和充電盒充電拼針 ,即可解決此問題。

(3).耳機放入充電盒 ,蓋上蓋子 ,充電盒的充電指示燈不亮 原因

1. 由于髒汙 ,灰塵 ,油脂等原因導致 ,耳機充電pin針和充電盒充電 pin 針不能

完整接觸。耳機沒有進入充電狀態。

方案1.

使用包裝盒內佩戴的軟布擦拭耳機和充電盒充電拼針 ,即可解決此問題。

(4).耳機連接電視沒有聲音/耳機不能自動回連電視 原因1.經過我們分

析 ,全球電視品牌 ,索尼 ,三星 ,華為 ,海信 ,TCL等品牌 對於藍牙

耳機的設置優先級不同 ,這個是由于不同設計UI決定。

方案1 :在電視端 ,設置耳機 ,電視音箱的播放優先級。

6.NCC警語

取得審驗證明之低功率射頻器材,非經核准,公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。低功率射頻器材之使用不得影響飛航安全及干擾合法通信;經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。前述合法通信,指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用電波辐射性電機設備之干擾。

