

Wireless Barcode Scanner

Quick Start Guide

System Settings



Restore Wireless Defaults



Version

Data Format



GB2312



Unicode(UTF-8)

Note: This product supports wireless 2.4G receiver and wired USB interface to directly output GB2312 or Unicode encoding

Data Transfer Mode



Synchronous Mode*



Storage Mode

Data Control



Upload All Data



Total Data Uploaded



Clear All Data

Wireless 2.4G Pairing

Wireless 2.4G mode supports Windows, Mac OS, Linux, Unix, Android and other systems.

Step 1: Scan the "Wireless 2.4G Mode" setting code;
After the setting is completed, the receiver that has been paired last time will be prioritized by default.



Wireless 2.4G Mode

Step 2: Scan the "One-click Pairing" setting code;
The blue light of the bar code flashes quickly and enters the 2.4G pairing state.



One-click Pairing

Step 3: Plug the receiver into the host (within 1 minute),hear a "Di", and the blue LED2 stays on. The connection is paired successfully.

Suffix Settings

Add CR*

Add LF

Add CR+LF

Add Tab(HT)

NONE

Vibration Setting(optional)

Enable*

Disable

Sound Settings

High*

Low

Disable

Sleep Time Settings

1 Minute

5 Minutes*

30 Minutes

Never Sleep

Sleep Now

Keyboard Language Settings

American English*

German

French

Spanish

Italian

Japanese

Portuguese

British English

Brazilian Portuguese

Russian

International Keyboard

LED Indicator Description

Blue LED1 flashes once:
---The scanner decoded successfully.
Blue LED2 is on:
---Connection succeeded.
Red LED3 is on:
---Battery is being charged, full off.
Blue LED1 flashes quickly:
--- The scanner is in the 2.4G pairing state.
Blue LED2 flashes quickly:
--- The scanner is in Bluetooth SPP mode pairing state.
Blue LED1 and blue LED2 blink rapidly alternately:
Blue LED1 and blue LED2 flash quickly and synchronously:
--- The scanner is in the Bluetooth BLE mode pairing state.
Blue LED1 and blue LED2 flash slowly at the same time:
--- The scanner is in an upgraded state.

Warranty Card

User Name:
Telephone Number:
Address:
Product Name:
Model NO.:
Product Serial Number:
Purchase Date:
Problem Description:

Certificate

Product Name:
Model NO.:
Product Serial Number:
Date of Production:
Inspector:
The products meet the company's quality standards and industry standards, and the products are qualified.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.