



# QUICKSTART MANUAL

Before you begin controlling the Pergola, connect it to a Wi-Fi network, finish setup, and then share control with the final user. To do this, follow the steps below:

## 1. Assemble the pergola

Fully Assemble the pergola without connecting the transmission bar to the motor.

## 2. Download the Toscana Dynamic APP

To download the Toscana Dynamic app, go to the app store on your mobile device and search for “Toscana Dynamic” Then select and download the app. You can also select a link below:

- For Iphone:

<https://apps.apple.com/gt/app/toscana-dynamic/id1583821175>

- For Android:

<https://play.google.com/store/apps/details?id=com.toscanaglobal.dynamic>

## 3. Login with installer credentials

For administrative tasks such as configuring the pergola you have con access with an administrative account, please ask the authorized partner if don't have an account.

## 4. Verify Pergola Connections

Ensure all the connections are made correctly, also plug the wireless antenna for RF remote controller. Check the wiring diagram for detailed reference.

## 5. Connect the pergola to a power source

Connect the main power, after a few seconds the Dynamic will enter pairing mode, and you should hear 3 beeps on the device, (if you don't hear the beeps, check the wiring and power)

## 6. Register Dynamic

On the app, go to the register dynamic option and follow the steps to connect to the wireless network, follow the installer manual for detailed steps.

## 7. Pair remote control

On the app, select the remote control, click on the pair button you will hear a beep, then, on the remote control hold up and down buttons for 5 seconds and then release, you should hear two beeps, now you can click on the pair button again to finish pairing. follow the installer manual for detailed steps and remote control usage references.

## 8. Setup Motor

Select the motor and click on the edit button on the left corner, then click on the setup option and follow the steps to define the limits of the operation of the pergola.

## 9. Register device and share to the client

Click on the options menu of the pergola (3 dots on the right top corner) and click on register again to share with the client, register all the information including client email, your client will receive an invite to install the Toscana Dynamic APP to control their device.

## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

### RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.