

Remote control directions

Remote Control Function Operation


- 1.Power Switch (Power button) : Click Power Switch for 1st time, turn on, default 1st gear; Click Power Switch for 2nd time, power off.
- 2.Fan Gear Selection (Fan shape) : When the fan is powered on: Click Fan Switch for 1st time, Fan 2nd speed; Click Fan Switch for 2nd time, Fan 3rd speed;Click Fan Switch for 3rd times, Fan 4th speed; Click Fan Switch for 4th times, switch to natural wind mode; Click Fan Switch for 5th times, Fan 1st gear...cycle.
- 3.Timer Selection (clock shape) : Click Timing Switch for 1st time, timed for 1H; Click Timing Switch for 2nd time, timed for 3H; .Click Timing Switch for 3rd times,timed for 6H; Click Timing Switch for 4th times, turn off timing (restore the current fan gear function).
- 4.Night light (Bulb shape) : First press button to turn on the night light (slightly bright);Second press button to switch to bright light; Third press to turn off night light.

Remote Control Usage Method



Please pull out the power isolation card before using the remote control, so that the remote control can be used normally. When not in use for a long time, insert the power isolation card back to avoid battery damage.

Product Component



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.