

# Bluetooth Rock Speaker

## Quick Start Guide

**MODEL NO.: HE-RS8GPBT**

### **Wiring the Speakers :**

1. Determine the ideal location where the Speakers are not exposed directly to the elements. Note: speakers typically should be placed between 8 to 12 feet apart for proper stereo separation.
2. The Master Speaker needs to be located near an AC outlet where you can connect the Power Supply to the Master Speaker in order provide the electrical current needed for the Internal Stereo Power Amplifier and Bluetooth Receiver.
3. The Pairing speaker must be connected to the Master Speaker with Waterproof Audio Cable. The length of the Audio cable is 5m (16.4 feet).

**Dongling Function:** Outdoor Rock Speaker. Equipped with 7 different colors of lights. At night, it will automatically turn on and the lights will smoothly change color in a cycle.

### **Initial Set-Up :**

1. Power on outdoor Bluetooth Rock Speakers
2. Turn ON iPhone, Android, or Other Bluetooth Device Open the Blue Tooth Function  
Search Blue Tooth Device: "RS4 S"
3. Touch device "Bluetooth" for automatic connection Play Music via Android or iTunes  
Control Volume via Bluetooth Device and Enjoy.



Smart Phone



Tablet



Laptop/Computer



Bluetooth

### **WARRANTY**

All speaker products come with a one-year limited warranty that covers defects in materials and workmanship. Proof of purchase must be provided with all warranty claims. During the warranty period, we will replace any defective parts and correct any workmanship defects free of charge, including both parts and labor costs. Our company's Technical Support Center is available from Monday to Friday, excluding holidays. If you need any assistance, please feel free to contact our customer service at any time!

**FCC Requirement :**

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**INDUSTRY CANADA:**

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
- (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
- (3) This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

Cet émetteur ne doit pas être co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 centimètres entre le radiateur et votre corps.

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS (s). Operation is subject to the following two conditions:

(1) This device may not cause interference.

(2) This device must accept any interference, including interference that may cause undesired operation of the device.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

(1) L'appareil ne doit pas produire de brouillage;

(2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.

Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

Cet émetteur ne doit pas être co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 centimètres entre le radiateur et votre corps.

## **Wiring the Speakers :**

Please turn off and unplug your system prior to making any connections. To wire your system, use good quality cable with polarity coding (usually identified with a marking on the cable). You must select wire that is suited for outdoor usage (look for wire that is rated for burial). Use 16 gauge speaker wire for up to 40ft and 14 gauge speaker wire for more than 40 ft. Connect the positive lead of the speaker wire (indicated with "+") to the red (+) speaker terminal. Connect the negative lead of the speaker wire to the black (-) speaker terminal. Connect the other end of the speaker wire to the respective inputs on the amplifier. See diagram above.

### Outdoor Rock Speaker Technical Parameters

MODEL NO.:	HE-RS4GBTGY-SLRLE-US
HVIN:	HE-RS4GBTGY-SLRLE-US
WOOFER :	4 inch woofer PP cone Poly Cone with Butyl Rubber Surround
SIGNAL-TO-NOISE RATIO :	88 dB
IMPEDANCE :	4 Ohms
MAX POWER CONSUMPTION	160W
FREQUENCY RESPONSE RANGE :	60HZ-10KHZ
UNIT PRODUCT DIMENSIONS :	L-265mm*W-232mm*H-242mm

### WARRANTY

All speaker products come with a one-year limited warranty that covers defects in materials and workmanship. Proof of purchase must be provided with all warranty claims. During the warranty period, we will replace any defective parts and correct any workmanship defects free of charge, including both parts and labor costs. Our company's Technical Support Center is available from Monday to Friday, excluding holidays. If you need any assistance, please feel free to contact our customer service at any time!