


70x80mm

English


USER MANUAL

JS761 TWS Earbuds




Please read this before use

Connect



1. Take the earbuds out the charging case and they will auto power on.





2. After open the phone Bluetooth, Click the <JS761> to Pairing




Reset

- Delete the BT pairing information on the phone.
- When powered on and not connected, quickly click Earbuds L/R control area "6 times(X6)" (If the above operation does not work, please try again)




Operation






X1: Click Once
X2: Click 2 times



2S: Press and hold for 2 seconds
3S: Press and hold for 3 seconds



3S: Press and hold for 3 seconds



ANC

X3: Click 3 times
4S: Press and hold for 4 seconds
8S: Press and hold for 8 seconds

Specifications


BT Version:	V5.3
Frequency:	2.402~2.480 GHz
BT Range:	33 feet without obstacle
Noise Reduction Mode (Long Press MFB for 4S):	ANC on/ANC Off /Transparency mode
Earbud Battery:	3.7V 40mAh
Charging Case Battery:	3.7V 300mAh
Microphone:	Si,-42dB+3dB
Speaker:	Φ10mm, 32Ω, 1mW
Charging Input Current:	DC 5V 1A
Charging port:	Type-C
Type-C port Charge Time:	About 2 hours
Earbud Work Time per Charge(at 50% volume):	About 6 hours

Diagram & Button Operations

Microphones

Microphones

Charging case indicator



TYPE-C Charging port

FAQ

Q1: The product can't pair with my phone.

- Please turn off the BT of other devices, make sure the earbuds are in pairing mode.
- Clear the pairing history of the earbuds and your phone. Turn off the BT then turn on, and try again.

Q2: The BT range or the sound quality is not good.

- BT signal can be blocked by surrounding objects thus affect the audio quality, if no obstacle between the product and your phone, the range and sound quality will be better.
- Keep away from other BT devices, microwaves, wireless routers, and other electronics.

Q3: Why there is a delay?

There is a data transmission process from your phone to the product, so sometimes you can feel delay. It's a common issue for all the BT devices, and BT V5.3 already made it better than the old versions.

Q4: Why the case can't charge the earbuds, or the earbuds won't power off after put back in case?

- If the case has no power, then above issues happen, please charge the case, and it will turn normal after the case has power.
- Please make sure you didn't put the right & left earbuds in the opposite place, and the magnet contacts well.
- If the earbuds come with charging insulation sticker on the metal contacts, please make sure you removed them before charge.

Q5: Why people can't hear me in the call?

Please make sure you wear 2 earbuds when making calls, and check if there is any dirt blocked the microphone.

Q6: Only 1 earbud pair with my phone.

- You need to let the L&R earbuds pair first, and then turn on phone Bluetooth to pair with the earbuds.
- If the L&R earbuds can't pair with each other, please do the clear pairing history operation, then try again.

Q7: The voice is low.

Please make sure you have tuned your phone volume to max level, and the earbuds fit well into your ear.

FCC Compliance Statement

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause

harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Warning Statements

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

CORRECT DISPOSAL OF THIS PRODUCT



(Waste Electrical & Electronic Equipment) This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household user should contact either the retailer where they purchased this product or their local government office for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

Made in China

