



LED UMBRELLA LIGHT SPEAKERS


USER MANUAL
LED UMBRELLA LIGHT

Thank you for purchasing LED umbrella light. Please read this user manual carefully firstly. We will introduce some of the important features and operating procedures of this product. Please keep this manual in a safe place for future reference.

SPECIFICATIONS


Item	Data
Color temperature	3000K/6500K
light	180LM
Light Source	60LED
Audio frequency	87.5~108.0MHZ
Battery	3.7V/4000mAh
Charging voltage	DC 5V/1A
Speaker	4Ω5W
Power	5W
Control method	Remote Control
Product Size	Ø 160*H70mm

STRUCTURE DIAGRAM



- ① lampshade
- ② Speaker
- ③ Fixed disk
- ④ Fixed buckle
- ⑤ Hanging hole
- ⑥ switch
- ⑦ Indicator light
- ⑧ charging port

REMOTE CONTROL INSTRUCTIONS



 Power On/Off

 Bluetooth/Radio selection

 Light color temperature selection/light off

 Previous Piece

 Play/Pause/Radio Search

 Next Track

 Volume Up

 Volume Down




Mute



Brightness plus



Brightness reduction



~



FM frequency selection

INSTRUCTIONS

- 1 Installation: Take off the fixing plate, fix it on the bottom of the center of the umbrella rib with the attached elastic hook, and then fix the product on it.
- 2 Lighting: The power switch is set to ON, the indicator light flashes, and the lighting light is on. Press "CCT" to select the desired light color, and press again to turn off the light.
- 3 Bluetooth: Turn on the Bluetooth of the mobile phone, search for the "GR-60L" device, after the pairing connection is successful, you can use the mobile phone to play music, and the remote control can control the music.
- 4 Radio: switch to radio mode, click the "play/pause" button to automatically search for radio stations and save them. After the search is completed, you can click the "previous" or "next" button to select a radio station, or you can use the number keys to search for a radio station, such as : 107.1MHZ, press 1071 to listen.
- 5 Charging: When the battery is low, please use the supplied charging cable to connect to the DC5V adapter for charging, and it will be fully charged in 4 to 5 hours.
- 6 The default function of this product is Bluetooth mode, the default brightness of the light is 80%, and the default volume is 80%. The operation can be changed with the remote control.

■ CAUTIONS AND WARNINGS

- 1 Do not repair, disassemble or modify the product without authorization.
- 2 Do not use in the sun or in high temperature environments.
- 3 This product is not waterproof.
- 4 Ensure that the installation is firm.
- 5 The length of the running time is determined by the brightness and volume of the light.
- 6 Please plug in the charging cable as an antenna when receiving.
- 7 Do not touch the appliance with wet hands or with liquids.
- 8 Do not overload the circuit, otherwise it may cause electric shock or fire.
- 9 Don't make the volume too loud at night, so as not to affect others.

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.