

T680 无线耳机使用说明

FCC ID: 2AZBO-N00034

请仔细阅读本指南并妥善保管以备将来使用

用户指南

感谢您选用本产品，为了您更好的使用本产品，请在使用前仔细阅读快速入门指南，并妥善保存。

- T680 无线耳机，双耳高清通话
- 根据人体工学原理，贴合耳蜗，佩戴舒适，即使运动也不易掉落。

耳机参数

电池容量: 3.7V/35mAh

音乐播放: 4-5 小时

充电时间: 1.5 小时

双耳通话: 4 小时

重 量: 5g

充电仓参数

电池容量: 3.7V/300mAh

充电时间: 1.5 小时

总续航: 12 小时 (可充满耳机 3 次)

尺寸大小: 60*46.8*26.2mm

产品重量: 45g

耳机操作

接听: 触摸左/右耳机一次,

挂断: 触摸左/右耳机一次,

拒接: 来电时, 长按两秒触摸键,

加减音量: 快速触摸三次右耳加音量, 触摸三次左耳减音量,

播放/暂停: 音乐中, 触摸左/右耳机一次播放/暂停音乐,

上下换曲: 触摸两次右耳下一曲, 触摸两次左耳上一曲

降噪开/降噪关/通透模式切换:长按两秒触摸键,

启动语音助手: 三击触摸键

项目	操作方法	LED 状态
开机	从充电舱拿耳机自动开机或长按 3S 开机	LED 白绿灯交替闪
关机	耳机开机状态下放入充电舱关机并充电	耳机 LED 白灯亮, 充满后 LED 白灯灭
进入配对	开机自动进入配对模式	主耳白绿灯交替闪烁, 副耳白

		绿灯熄灭
连接成功	打开绿牙搜索蓝牙名: T680	LED 白绿灯灭
断开连接	自动进入配对模式	主耳白绿灯交替闪烁,副耳白绿灯熄灭
回连	开机自动回连	无
蓝牙无连接自动关机	开机后无任何操作约 5 分钟后自动关机	所有 LED 灯灭
耳机充电中	耳机放回充电舱内	LED 白灯亮
耳机充满电	耳机在充电舱内	LED 白灯灭
低电报警	电量低于 3.3V, 耳机提示“嘟.. 哒..”语音	主副机白灯 3 秒闪 1 次, 3V 时自动关机 (10 分钟左右)

配戴图示

保养与保存

保持耳机清洁对于安全、卫生的使用很重要

1. 请勿佩戴已显肮脏的入耳式耳机;
2. 耳机不使用时, 请始终将其存放在洁净干燥的环境中;
3. 请勿与其他物品存放一起, 因为这样可能会造成污染;
4. 避免储存在过热过冷的环境中;
5. 避免接触液体, 并避免极端温度或高湿环境;
6. 请勿非专业, 不规范的拆解耳机, 以免造成耳机偏音

T680 Wireless Earphone User Manual

FCC ID: 2AZBO-N00034

Please read this guide carefully and safekeeping for future needs

User Guide

Thank you for choosing this product. For your better use of this product, please read the Quick Start Guide carefully before use and keep it properly.

·T680 wireless earphones, binaural high-definition call

·According to the principle of ergonomics, it fits the cochlea and is comfortable to wear, and it is not easy to fall off even if you exercise.

Earphone parameters

Battery capacity: 3.7V/35mAh

Music playback Time: 4-5 hours

Charging time: 1.5 hours

Talk Time: 4 hours

Weight: 5g

Charging Case parameters

Battery capacity: 3.7V/300mAh

Charging time: 1.5 hours

Total battery life: 12 hours (can full charge the headset 3 times)

Size: 60*46.8*26.2mm

Product weight: 45g

Headset operation

Answer Call: touch right/left ear

Hang up Call: touch right/left ear

Rejection: When a call comes in, Press and hold touch button for two seconds.

Volume up and down: Fast touch three times right ear to increase the volume, touch three time left ear to decrease the volume.

Play/Pause: In the music statue, touch right/left ear to play /pause music

Music move prev/next:

Fast touch tow times right ear to move next music, and touch tow times left earbuds to move music prev

ANC/Transparent mode switching: Press and hold touch button for two seconds.

Starting voice assistant: Fast touch three times right/left earbuds.

Active voice assistant: triple-click the touch button

Enter Pair	Automatic enter pair mode After power on	Host earbud Red& Blue crossing blink, minor earbuds Red&Blue LED close
Connected	Open bluetooth search Pair Name: T680	LED Red and Blue light close
Disconnect	Automatic enter pair mode	Host earbud Red& Blue crossing blink, minor earbuds Red&Blue LED close
Connection	Connection after Power On	N/A
Bluetooth disconnect and Auto power off	Automatically shut down after about 5 minutes without any operation after booting	All LED close
In charging	Place earbuds back charge case	LED Red lighting
Full charge	Earbuds in charge case	LED Red close
Lower Battery alarm	When the power is lower than 3.3V, the earphone prompts "beep..dong.."	Host and minor earbuds Red LED blink each 3 seconds and when 3V automatic shut off (Around 10mintues)

Wearing icon

Care and Preservation

Keeping your earphones clean is important for safe, hygienic use

1. Do not wear dirty earphones;
2. When the earphones are not in use, please always store them in a clean and dry environment;
3. Do not store it with other items, as it may cause pollution;
4. Avoid storing in an environment that is too hot or too cold;
5. Avoid contact with liquid, and avoid extreme temperature or high humidity environment;
6. Please do not disassemble the earphones in an unprofessional or non-standard way, so as not to cause the earphones to be out of tune

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This device generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this device does cause harmful interference to radio or television reception, which can be determined by turning the device off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the device and receiver.
- Connect the device into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment