

Magnetic wireless charger manual

Thank you for purchasing and using our products, to ensure that this product works for you
Bring a better user experience, please read the manual of this product first, and
Please also refer to the instruction manual of your mobile phone or electronic product.

Specification Description:

Interface type: type-c

Input parameters: 5V 3A, 9V/2A, 12V/1.5A (QC/PD/AFC)

Output power: 5W, 7.5W, 10W, 15W (Max 15W)

Product size: 61*6.5mm

Product unit weight: about 45g

Color: White

Instructions for use:

1. Connect the power cord to the Type-C adapter, and then plug the power adapter into
Socket;
2. Place the mobile device that supports wireless charging in wireless charging
Regionally.

Note: If you need to realize the wireless fast charging function, you can purchase the PD protocol
Type-C port adapter. (Mobile devices must meet the Qi standard before they can be used)

Precautions

1. Do not squeeze or bump the product forcefully.
2. Do not disassemble, disassemble or modify by yourself.
3. Do not put the product near the fire source or throw it into fire or water.
4. Do not use wireless in severe high temperature, humidity or corrosive conditions

Charger, avoid damaging the circuit and causing leakage.

5. Do not place it with magnetic cards (identity cards, bank cards, etc.) with magnetic strips or chips

Too close to avoid magnetic failure.

6. Do not put metal or metal phone cases on the wireless charger.

7. Please keep implanted medical equipment (pacemaker, implantable cochlea, etc.) and no

The distance between wired and wireless charging is at least 20cm to avoid damage to medical equipment

Cause potential interference.

8. Please keep the wireless charger away from water or other liquids.
9. If you need to clean the wireless charger, please make sure the power is disconnected.
10. Do not use as toys for children.
11. The use environment temperature is kept at 0-45°C

After-sales service

Warranty description (warranty scope is limited to the host computer, excluding accessories and gifts)

1. Within 12 months from the date of product purchase. If the product is damaged or malfunctions, The company's technical staff confirmed that it occurred under normal use, The company will provide free maintenance services;
The following situations will not be repaired free of charge:
 - .No warranty card or damaged product repair label.
 - . Damage caused by self-disassembly.
 - .Failure and man-made mechanical damage caused by water or falling damage.
 - .Product failure or damage caused by force majeure accidents or natural disasters.
2. The original card and the original invoice of the purchaser must be provided when repairing. If the user does not Can provide, free warranty is invalid, provide maintenance services, users may need to support Pay related maintenance costs;
3. Please use this product in accordance with the specifications, otherwise it will cause damage to your electronic equipment
Damage will not be within the scope of our company's responsibility.

FCC Warning

1. This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful

interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

RF Exposure:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance of 20 cm between the radiator and your body. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

FCC ID:2AZER-DW006