


Instruction of GDO-WWS02

Frequency: 433.92 MHz / 868.35 MHz Rolling-Code Battery:
CR2032 3V

Working Temperature: -40 ° C - +50 ° C

- Keep single button wireless wall switch out of reach of children
- Single button wireless Wall switch may only be operated by persons who are familiar with the system and have been instructed in their function
- Use the single button wireless wall switch only when you are in sight of the door / gate
- Coding in single button wireless wall switch must always be carried out within the vicinity of the door operator. Use only original parts
- Protect single button wireless wall switch from rain, snow, sunlight or dust, otherwise the function of the wall switch may be impaired
- To change the battery, loosen the screws on the rear of the single button wireless wall switch

Programming



- Open the cover of single button wireless wall switch (Fig.1)
- Fix the single button wireless wall switch on the wall with 2 screws (Fig.2)
- Close the cover of single button wireless wall switch (Fig.3)
- You need to replace the battery, when the red light is dark or flash (Fig.4)

Coding instruction

- Press the "Code" key on the display of your garage door operator. A dot (.) will appear in the corner. (Fig.5)



Figure 5




Figure 6

- Press the button of single button wireless wall switch, the dot (.) on the display turn off, then press the button again, the dot (.) on the display will flash, this means you have finished the coding. (Fig.6)

WARNING! When teaching in a single button wireless wall switch, the operator may be accidentally triggered initiating door movement!

Information about battery regulation

As a dealer for the distribution of electronic, battery-operated devices, we are obliged by law to inform our customers about the following:

Electrical and electronic devices, as well as batteries, must not be disposed of as household or residual waste, but must be delivered in the appropriate acceptance and collection points will.

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC 's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.