

XIAMEN XINGFEIXIANG E-COMMERCE CO., LTD.

ROOM 311, 3TH FLOOR, NO. 2 MALONG ROAD, TORCH PARK, TORCH HIGH-TECH ZONE,
XIAMEN CHINA 361000

Magic Color Touch Remote Manual

Basic parameters


Control point figure: Maximum adjustable to 2048 pixels


Remote control distance: ≤ 30 meters

Battery model: AAA Battery (remote control battery)

Remote control operation instructions

 : On/off button (power on/off)

 : Pause button / Auto Play

 : Color ring (touch a color and the lamp strip will display the corresponding color)

M+: Mode plus (next effect)

M-: Mode minus (last effect)


S+: Speed up (the lamp runs faster)

S-: Slow down (the running speed of the lamp slows down)

B+: Increase brightness

B-: Decrease brightness



Light Effect Auto Play: press any key of color ring first, then press the button  to auto play from the first effect to the last effect.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.